


Canon

imageCLASS

D 1 3 7 0 / D 1 3 5 0 / D 1 3 2 0

Starter Guide



1



Preface

 Next Page

2



Installing the Machine

 P. 6

3



Configuring and
Connecting the Fax

 P. 14

4



Connecting to a Computer
and Installing the Drivers

 P. 18

 **Read this guide first.**

Please read this guide before operating this product.

The remarks for important safety instructions are described in "Basic Operation Guide." Read the guide also.


After you finish reading this guide, store it in a safe place for future reference.

Appendix

 P. A-1

Setting Up the Machine to Suit Your Needs

Specify settings related to the Copy, Print, Fax*1, PC Fax*1, Scan, Remote UI and ,Media Printing functions. Follow the steps in the flowchart below.



*1 You may use this function in the D1370/D1350 only.

Available Features

○: available —: not available


	Copy	Print (2-sided)	Print (PS/PCL)	Fax (PC Fax)	Scan	Send to E-mail/ Store to Shared Folder	Remote UI	ADF (2-sided)
D1370	○	○	○	○	○	○	○	○
D1350	○	○	—	○	○	—	○	○
D1320	○	○	—	—	○	—	○	○

Checking the Supplied Accessories

1. Confirm that all the supplied accessories are contained in the box.

If an item is missing or damaged, please contact our Canon Authorized Service Facilities or the Canon Customer Care Center.

- The machine unit
The toner cartridge is already installed.



About the LAN cable

The machine does not come with a LAN cable or a hub. Have cables or a hub ready as needed.

- Use a Category 5 or higher twisted pair cable.
- If you want to connect the machine to a 100BASE-TX Ethernet network, all the devices to be connected to the LAN must support 100BASE-TX.

- Power cord



About the USB cable

The machine does not come with a USB cable. Have cables ready as needed.

- Telephone cable *1



- Starter Guide (This manual)




- Speed dial label*1



- Basic Operation Guide



- User Software CD-ROM



- Limited Warranty Notice



*1 D1370/D1350 Only

Supplied Toner Cartridge

The average yield of the included toner cartridge is as follows.

Canon Cartridge 120 Starter	Average yield*1: 2,300 sheets
-----------------------------	-------------------------------

*1 The average yield is on the basis of "ISO/IEC 19752"^{*2} when printing A4 size paper with the default print density setting.
 *2 "ISO/IEC 19752" is the global standard relating to "Method for the determination of toner cartridge yield for monochromatic electrophotographic printers and multi-function devices that contain printer components" issued by ISO (International Organization for Standardization).

The average yield of the replacement toner cartridge varies from that of the supplied toner cartridge.
 To purchase replacement toner cartridges, see "About Replacement Toner Cartridges" in the e-Manual.

User Software CD-ROM

About the Drivers and Software

The drivers and software included in the CD-ROM supplied with this machine are as follows.

MF Drivers

Printer driver	You can print from an application to the machine once you have the printer driver installed on your computer. Printer Drivers: UFR II LT/UFR II (XPS)PCL5e/PCL6/PS Printer Driver * The appropriate Printer Driver differs according to your machine. • UFR II (XPS) is for Windows Vista/7/8/Server 2008/Server 2008 R2/Server 2012 only. • PCL5/PCL6 is for Windows only.
Fax driver (D1370/D1350 only)	If you install the fax driver on your computer, you can select "Print" from an application, select the Canon fax driver as a printer, and specify the output destination and options. The fax driver converts the data into an image that conforms to standard fax protocols so that the data can be printed or saved using the recipient's fax machine.
Scanner driver	You can use the machine as a scanner once you have the scanner driver installed on your computer.
Network Scan Utility	You need this utility software to use the machine as a network scanner. It is automatically installed along with the scanner driver.

The newest software

Depending on the operating system you are using, some functions of the driver software included in the CD-ROM may not be usable. The newest software is posted on the Canon web site. Please verify the operating environment etc. and download the appropriate software if required.

MF Toolbox

MF Toolbox*	The MF Toolbox provides a group of commands for you to open a scanned image in an application, send it as an e-mail attachment file, store it on the hard disk, etc.
-------------	--

Others

Presto! PageManager	You can handle scanned images in many ways using this software.
---------------------	---

* MF Toolbox for Macintosh and MF Toolbox for Windows may be different in some features. For details, see the Scanner Driver Guide.

Supported Operating Systems

○: Supported —: Not supported

	Windows XP	Windows Vista/7/8	Windows Server 2003	Windows Server 2008	Windows Server 2008 R2/Server 2012	Mac OS X (version 10.5.8 or later)
Printer driver	○	○	○*	○*	○*	○
Fax driver	○	○	○*	○*	○*	○
Scanner driver	○	○	—	—	—	○
Network Scan Utility	○*	○*	—	—	—	—
MF Toolbox	○	○	—	—	—	○
Presto! PageManager	○	○	—	—	—	—

* Supported only over network connections.

About the Supplied Manuals

Read this manual first.

This manual describes the settings for setting up the machine and installing the software. Be sure to read this manual before using the machine.

Starter Guide

This manual



- Preface
- Installing the Machine
- Configuring and Connecting the Fax*
- Connecting to a Computer and Installing the Drivers
- Appendix

* The fax function is available only for D1370/D1350.

Read this manual next.

This manual describes the basic use of the machine.

Basic Operation Guide



- Before Using the Machine
- Document and Paper Handling
- Copying
- Printing from a Computer
- Registering Destinations in the Address Book*
- Using the Fax Functions*
- Using the Scan Functions
- Maintenance
- Troubleshooting
- Registering/Setting the Various Functions
- Appendix

* The fax function is available only for D1370/D1350.

Read this manual for how to set Send features.

This manual describes setting for sending scanned data to E-mail and/or file servers.

Send Setting Guide

* The Send Setting Guide is included in the User Software CD-ROM.



- Send to E-mail Function
- Store to Shared Folder Function

Read the desired chapter to suit your needs.

The e-Manual is categorized by subject to find desired information easily. For details about using the e-Manual, refer to "Using the e-Manual" in "Appendix."

e-Manual

* The e-Manual is included in the User Software CD-ROM.



- Important Safety Instructions
- Basic Operation
- Copy
- Fax*1*2
- Print*2
- Scan*2
- Network Settings
- Security
- Setting and Managing from Computer
- Troubleshooting
- Maintenance
- Setting Menu List
- Specifications

*1 The fax function is available only for D1370/D1350.

*2 If you are using Macintosh, see the following Driver Guides or Help for more details on these functions.

You can find the driver guides in the following locations on the User Software CD-ROM.

- Canon MF Printer Driver Guide → [Documents] - [english] - [Guide] - [index.html]
- Canon PS Printer Driver Guide → [Documents] - [english] - [Print(PS)] - [Guide] - [index.html]
- Canon Fax Driver Guide → [Documents] - [english] - [FAX] - [Guide] - [index.html]
- Canon Scanner Driver Guide → [Documents] - [english] - [Guide] - [index.html]

Read this manual when installing the software.


MF Driver Installation Guide

* The MF Driver Installation Guide is included in the User Software CD-ROM.



- Before Using the Driver
- Installing the MF Drivers and MF Toolbox
- Installing the MF Drivers on the WSD Network
- Uninstalling the Software
- Troubleshooting
- How to Use the Online Help
- Confirming IP Address Settings
- How to Check the Bit Architecture


Determining the Installation Site



Carrying the Machine to the Installation Site and Removing the Packing Materials

1. Take the machine out of the plastic bag, and then carry to the installation site.

1 Hold the grips.




2 Carry the machine.




2. Remove the packing materials.

* The packing materials may be changed in form or placement, or may be added or removed without notice.


1 Remove the unpacking manual.



2 Remove the packing materials.




3 Remove the packing materials.




* Do not remove the cap (A) on the USB port at this stage. Uncap when installing for USB connection.


4 Open the feeder.




5 Remove the packing materials with tape.




6 Close the feeder.




7 Pull out the paper drawer.



8 Remove the packing materials with tape.




9 Set the paper drawer.




Check!

Make sure that the following packing materials are all removed from the machine.

- Tape x 20 (D1370/D1350)
x19 (D1320)



- Packing materials with tape x4




- Unpacking manual x1




Preparing the Toner Cartridges

1. Open the front cover.

1 Hold down the open button.




2 Open the front cover.




2. Remove the packing materials from the toner cartridge, and install the toner cartridge.


1 Remove the packing material.




2 Remove the toner cartridge.



3 Remove the packing material.




4 Shake five to six times.



5 Remove the tab.

Place the toner cartridge on a flat surface, and remove the tab.




6 Pull the sealing tape completely out.

The full length of the sealing tape is approximately 20 in. (50 cm).

7 Insert the toner cartridge.

Fit the protrusions on both sides of the toner cartridge into the guides located on both sides of the machine, and slide the toner cartridge into the machine until the toner cartridge comes to rest and is held against the back of the machine.




Check!


Make sure that the following packing materials are all removed from the machine.

Packing materials x2


Sealing tape x1



3. Close the front cover.



Write down the serial number and purchase date on the back cover of the Basic Operation Guide enclosed in the package. You need this information when contacting your local authorized Canon dealer or Canon Customer Care Center.




The serial number is located on the rating label centered on the rear side of the machine (a character string of 3 letters and a 5-digit number).



Write down the information here (on the back cover of the Basic Operation Guide).


○ Loading Paper

1. Pull out the paper drawer.



2. Slide the paper guides, and load the paper.

- 1 While holding the lock release lever, adjust the paper guides.
Match the paper guides with the size of the paper that is loaded.



When changing the size of the paper to be loaded


Be sure to set the paper size.

At factory shipment, the machine's default settings have LTR for paper size and Plain for paper type.


- ➔ Proceed to "Setting a Paper Size and Type" on p.13.

2 Load the paper.

Load the paper that it aligns with the rear side of the paper drawer.




3 Set the paper under the hooks.




Check!

Make sure that the paper stack does not go over the line of the load limit mark.




3. Set the paper drawer.




Connecting the Power Cord


1 Make sure that the machine is switched OFF.



2 Plug the power plug into the power socket.



3 Plug the power plug into an AC power outlet.




Do not connect the USB cable. Connect the USB cable when installing the software.

Turning On the Machine and Specifying the Initial Settings

1. Turn ON the machine.

- When turning ON the machine for the first time after installation, it may output a piece of blank paper. This is not a failure.
- The machine enters the Sleep mode to conserve energy when you do not operate the machine for a certain period of time. To cancel the Sleep mode, press the  (Energy Saver) key on the operation panel.




2. Specify initial settings.


- 1 Press [▲] or [▼] to select, and press [OK].




- 2 Press [▲] or [▼] to select, and press [OK].




- 3 Read the messages and press [OK].




- 4 Press [▲] or [▼] to select, and press [OK].



- 5 Enter the date and time and press [OK].



- 6 The initial screen appears when the initial setup is complete.




- Move the cursor with [◀] or [▶].
- Press [▲] or [▼] to select the number or switch to <AM> or <PM>.

Setting a Paper Size and Type


1 Press [] (Select Paper/Settings).




2 Press [▲] or [▼] to select, and press [OK].




3 Press [▲] or [▼] to select, and press [OK].



4 Press [▲] or [▼] to select, and press [OK].



5 Press [▲] or [▼] to select, and press [OK].



6 Press [] (Select Paper/Settings) to close <Select Paper> screen.

• For D1370/D1350

Next, perform the setup to use the fax function.

Specifying Initial Fax Settings and Connecting a Telephone Cable

➔ P.14

• For D1320

Next, select the connection method to a computer.

Selecting the method for connecting to the machine

➔ P.18

Specifying Initial Fax Settings and Connecting a Telephone Cable


Operate the machine following the on-screen instructions and perform the following settings and connection.

- Registering the fax number and unit name
- Setting the fax receive mode
- Connecting a telephone line

If you are using pulse dialing, change the line type after specifying the settings.

Entering Text

Enter information (text, symbols, and numbers) using the following keys.



Changing the entry mode

Press [▼] to select <Entry Mode> and press [OK]. You can also press [*] (Tone) to change the entry mode.

Entry mode	Text that can be entered
<A>	Alphabet (capital letters) and symbols
<a>	Alphabet (small letters) and symbols
<12>	Numbers

Moving the cursor (entering a space)

Move the cursor by pressing [◀] or [▶]. To enter a space, move the cursor to the end of the text and press [▶].

Entering text, symbols, and numbers

Enter using the numeric keys or [#] (SYMBOLS).

Key	Entry mode: <A>	Entry mode: <a>	Entry mode: <12>
1		@ . - _ /	1
2	ABC	abc	2
3	DEF	def	3
4	GHI	ghi	4
5	JKL	jkl	5
6	MNO	mno	6
7	PQRS	pqrs	7
8	TUV	tuv	8
9	WXYZ	wxyz	9
0	(Not available)		0
#	- . * # ! " , ; : ^ ` _ = / ' ? \$ @ % & + \ () [] { } < > ~		(Not available)

Deleting text, symbols, or numbers

To delete text, numbers, or symbols, press [C] (Clear).


To delete all text, numbers, or symbols, press and hold [C] (Clear).

1. Register the fax number and unit name.

1 Press [FAX].




2 Press [▲] or [▼] to select, and press [OK].



3 Press [OK].

Register the unit telephone number for this machine.
*Next Screen: Press OK

4 Enter.




Display "Fax Setup Guide" with the following operations to perform the settings or connections if selecting <Set up Later>.
[*] (Menu) → <Fax Settings> → <Fax Setup Guide>.

5 Press [▲] or [▼] to select <Apply> and press [OK].

6 Press [OK].

Register unit name.
(Sender name, company name, etc.)
*Next Screen: Press OK


7 Enter.



8 Press [▲] or [▼] to select <Apply>, and press [OK].

What happens with the unit name

Once the information has been registered, it is printed at the top of each page that you are sending.




2. Select the fax receive mode.

You can specify how the machine should operate for a fax call or telephone call.


By answering the prompts that appear on the display, the machine will be set to one of the following four operation modes.

<Auto><Fax/Tel Auto Switch><Answer><Manual>




Yes

No



Yes

No



Yes

No

The receive mode is set to <Auto>.
→ Proceed to Step 3.

- Receive faxes automatically.
- The telephone functions do not be used.*

* When the telephone is connected in the auto receive mode, the telephone rings when receiving a fax or telephone call. You can answer the telephone while it is ringing. To turn off the telephone ringer, see "Incoming Ring" in the e-Manual.

The receive mode is set to <Fax/Tel Auto Switch>.
→ Proceed to Step 3.

- Receive faxes automatically.*
- Responds to a telephone call by picking up the handset.

* The telephone rings on incoming calls. To turn off the telephone ringer, see "Incoming Ring" in the e-Manual.

The receive mode is set to <Answer>.
→ Proceed to Step 3.

- Receive faxes automatically.
- Respond to telephone calls using the built-in answer function.
- Ring on incoming calls or faxes.

The receive mode is set to <Manual>.
→ Proceed to Step 3.

- Respond to incoming calls or faxes by picking up the handset.
- Ring on incoming calls or faxes.

3. Connect the telephone line.


- 1 Press [OK].

The screen that appears varies, depending on the receive mode selected.

Connect phone line.
Follow illustrations
on the next screen:
Connect line to A.
*Next : Press OK


Connect phone line.
Follow illustrations
on the next screen
to make connections:
1. Phone line to A

- 2 Connect the telephone line using the jack.




To connect an external telephone that includes fax functions
Make sure to disable its automatic fax reception feature
so it does not receive faxes automatically.

- 3 Press [OK] after the telephone line has been connected.



- 4 Press [◀] to select, and press [OK].

- 5 Press [OK].



Fax settings and connections have been completed.

- 6 Restart the machine for the settings to take effect.

Turn OFF the machine, wait for at least 10 seconds, and turn it back ON.

4. Change the line type.

By default, the telephone line type is set to tone dialing. Skip the following steps in the procedure below when you choose to use tone dialing.

Follow the steps in the procedure below to select pulse dialing.

Contact your local telephone company when you are not sure of the line type that you are using.


- 1 Press [] (Menu).
- 2 Press [] or [] to select <Fax Settings> and press [OK].
- 3 Press [] or [] to select <Basic Settings> and press [OK].
- 4 Press [] or [] to select <Select Line Type> and press [OK].
- 5 Press [] or [] to select the line type that you are using and press [OK].
 - <Pulse>: Pulse dialing
 - <Tone>: Tone dialing (Default)
- 6 Press [] (Menu) to close the menu screen.

Selecting the method for connecting to the machine

Select from the following three methods, depending on your environment and devices.

Connecting via a USB Cable

Connect them using a USB cable.



You need this


USB cable



- Windows
 - Installing the USB connection P.22
- Macintosh
 - Installing the software P.25

Connecting via a LAN Cable

Connect them using a LAN cable.



You need this

Router
or
hub

LAN cable



➤ Connecting to LAN P.19

Use the same procedure for both Window and Macintosh.

- * Check to make sure that there is a free port for connecting the machine or the computer you use to the router or hub.
- * Use a Category 5 or higher twisted pair cable for the LAN.


Connecting to LAN

Before adding the machine to a wired LAN

Check to make sure that the computer is connected by a LAN cable to a router or hub, and that the network setup is completed.

If it is not set up, you will not be able to use the machine on the wired LAN network even if you perform the following steps.


- The structure of your computer or networked device, the existence of router functions, setting methods and security settings vary depending on your environment.
For more information, see the instruction manual provided with the network device you are using, or contact the manufacturer.
- If using the machine in your office, consult with your network administrator.



Precautions when connecting to a wired LAN

- The structure of your computer or networked device, the existence of router functions, setting methods and security settings vary depending on your environment.
- If using the machine in your office, consult with your network administrator.

1. Connect the LAN cable.



About the LAN cable

- The machine does not come with a LAN cable or a hub. Have cables or a hub ready as needed.
- Use a Category 5 or higher twisted pair cable for the LAN.

2. The machine sets the IP address automatically. Wait approximately 2 minutes.

If you want to set the IP address manually, see the following.

- ➡ e-Manual "Setting IPv4 Address"
- ➡ e-Manual "Setting IPv6 Address"

About obtaining the IP address automatically (AutoIP)

<DHCP> or <Auto IP> is enabled in the default setting. Even if you do not set the IP address manually, this machine can obtain it automatically.

- Even if you do not have a dedicated device such as a DHCP server, the IP address is obtained automatically.
- The <DHCP> setting is prioritized over <Auto IP>.

If a fixed IP address is set as the IP address of the computer, set the fixed IP address also for this machine manually.

If the IP address of the machine is changed

When the machine and computer are on the same subnet, the connection is maintained.

Installing via Network Connection

- For Windows
 ➡ Installing via Network Connection P. 20
- For Macintosh
 ➡ Installing the Software P. 25

Installing via Network Connection (For Windows)

1. Check the following points.

- The computer and machine are connected via the network.
- The power of the machine is turned ON.
- IP address is properly set up. ➔ Proceed to P.A-3 "Checking the IP Address"


2. Turn on the computer, and then log on as a user with administrative privileges.

If you have already logged on, exit all applications which are running.


3. Install the MF Drivers and MF Toolbox.

- * If you are operating in the IPv6 environment, you may not install the drivers or software following the procedures below. Refer to "Installing the MF Drivers on the WSD Network (For Windows)" in the MF Driver Installation Guide.
- * You may not use the scan function in the IPv6 environment.

1 Insert the CD-ROM.



2 Click.



[Easy Installation] performs the installation of the following software.


- Printer driver
- Fax driver (D1370/D1350 only)
- Scanner driver
- MF Toolbox
- e-Manual

To add the following software and manual to the installation, select [Custom Installation].


- Presto! PageManager
- ➔ MF Driver Installation Guide "Installing the MF Drivers and MF Toolbox"

If the top screen does not appear

- Windows XP and Server 2003
 1. From the [Start] menu, select [Run].
 2. Enter "D:\Minst.exe", and then click [OK].
 - Windows Vista, 7, and Server 2008
 1. Enter "D:\Minst.exe" in [Search programs and files] or [Start Search] under the [Start] menu.
 2. Press the [ENTER] key on the keyboard.
 - Windows 8 and Server 2012
 1. Right-click the lower-left corner of the screen and select [Run].
 2. Enter "D:\Minst.exe", and then click [OK].
- * The CD-ROM drive name is indicated as "D:" in this manual. The CD-ROM drive name may differ depending on the computer you are using.




3 Click.




4 Click.

5 Read the contents of the License Agreement.




6 Click.




7 Click.

If the following dialog box appears



Click.

8 Select.



9 Click.

If no devices are displayed in [Device List] Perform the following procedure.

1. Check the following.
 - The computer and device are connected via the network.
 - The device is turned on.
 - The IP address is set correctly.
 - The computer and device are on the same subnet.
 - Security software has been exited.


2. Click [Update Device List].

If any devices are not displayed by performing the above procedure, perform the following procedure.

1. Click [Search by IP Address].
 2. Enter the IP address of the device to be installed.
- ➔ Proceed to P.A-3 "Checking the IP Address"




3. Click [OK].



10 Click.

The installation starts.



11 Click.

Next, installation of MF Toolbox starts.

* In Windows Server /2003/2008/2012, MF Toolbox is not installed. Proceed to Step 14.




12 Click.

14 Ensure that [✔] is added.



13 Click.



15 Click.

16 Select the check box.



17 Click.

The CD-ROM may be removed once this screen appears.

Checking the Installation Results

➔ P. 24

Installing with USB Connection (For Windows)

- Connect the USB cable after installing the software.
- Ensure that the power of the machine is turned on when connecting the USB cable.

To use Printer Driver other than UFR II through the USB connection

You need to change the machine setting beforehand. Choose the PDL (Printer Driver) that you want to use and follow the procedures shown below. Press [] (Menu) → <System Settings> → <Select PDL (Plug-n-Play)> → <USB> → Select the PDL (Printer Driver) that you want to use


*The appropriate Printer Driver differs according to your machine.

1. Turn on the computer, and then log on as a user with administrative privileges.


If you have already logged on, exit all applications which are running.

2. Install the MF Drivers and MF Toolbox.

1 Insert the CD-ROM.



2 Click.



[Easy Installation] performs the installation of the following software.


- Printer driver
- Fax driver (D1370/D1350 only)
- Scanner driver
- MF Toolbox
- e-Manual

To add the following software and manual to the installation, select [Custom Installation].


- Presto! PageManager
- MF Driver Installation Guide "Installing the MF Drivers and MF Toolbox"

If the top screen does not appear

- Windows XP and Server 2003
 1. From the [Start] menu, select [Run].
 2. Enter "D:\Minst.exe", and then click [OK].
 - Windows Vista, 7, and Server 2008
 1. Enter "D:\Minst.exe" in [Start Search] or [Search programs and files] under the [Start] menu.
 2. Press the [ENTER] key on the keyboard.
 - Windows 8 and Server 2012
 1. Right-click the lower-left corner of the screen and select [Run].
 2. Enter "D:\Minst.exe", and then click [OK].
- * The CD-ROM drive name is indicated as "D:" in this manual. The CD-ROM drive name may differ depending on the computer you are using.




3 Click.




4 Click.

5 Read the contents of the License Agreement.




6 Click.



7 Click.

If the following dialog box appears



Click.




8 Click.

Next, installation of MF Toolbox starts.

* In Windows Server 2003/2008/2012, MF Toolbox is not installed. Proceed to Step 11.




9 Click.




10 Click.

11 Ensure that [✓] is added.



12 Click.

13 Select the check box.




14 Click.

The CD-ROM may be removed once this screen appears.


3. Connect the USB cable.

1 Remove cap plug.
Remove by pulling the string.



2 Connect the cable.

- Flat end (A):
Connect to the USB port on the computer.
- Square end (B):
Connect to the USB port on the machine.



When a dialog box is displayed
Follow the on-screen instructions and complete the installation.

Checking the Installation Results

➔ P. 24

Checking the Installation Results (For Windows)

Ensure that the MF Drivers and MF Toolbox are installed correctly.

Ensure that the icons for the installed software are added as follows.

Refer to the "User Software CD-ROM" (P. 4) for the functions of each software.


Software	Location	Icon
Printer driver	Printer folder <ul style="list-style-type: none"> Windows XP Professional/Server 2003 From the [Start] menu, select [Printers and Faxes]. Windows XP Home Edition From the [Start] menu, select [Control Panel], click [Printers and Other Hardware] → [Printers and Faxes]. 	 Canon UFRLLT
Fax driver (D1370/D1350 only)	<ul style="list-style-type: none"> Windows Vista From the [Start] menu, select [Control Panel], and then click [Printers]. Windows 7 From the [Start] menu, select [Devices and Printers]. Windows Server 2008 From the [Start] menu, select [Control Panel], and then double-click [Printers]. Windows 8, and Server 2012 Right-click the lower-left corner of the screen, select [Control Panel], and then click [View devices and printers]. 	 Canon (FAX)
Scanner driver	[Scanners and Cameras] or [Scanners and Cameras Properties] folder <ul style="list-style-type: none"> Windows XP From the [Start] menu, select [Control Panel], and then click [Printers and Other Hardware] → [Scanners and Cameras]. Windows Vista From the [Start] menu, select [Control Panel], and then click [Hardware and Sound] → [Scanners and Cameras]. Windows 7 1. Enter "scanner" in [Search programs and files] under the [Start] menu. 2. Click [View scanners and cameras]. Windows 8 1. Right-click the lower-left corner of the screen and click [Control Panel]. 2. Enter "scanner" in [Search Control Panel] on the upper-right corner of the window. 3. Click [View scanners and cameras]. 	<ul style="list-style-type: none"> For network connection  WIA Canon ser_001E8FAE 6A30 For USB connection  WIA Canon Series
MF Toolbox	Desktop	 Canon MF Toolbox 4.9
Network Scan Utility	Taskbar	

How to Use the Online Help

In the Online Help, all the functions of the driver software and information about options are included. If you want to view descriptions of the functions and settings immediately when using the driver software, make use of the Online Help.

How to display the Help screen


- (1) Select [File] → [Print] from the menu bar in the application.
- (2) Select the printer in [Select Printer] or [Name] in the [Print] dialog box.
- (3) Click [Preferences] or [Properties].
- (4) Click [Help].



Installing the Software (For Macintosh)

- Connect the USB cable after installing the software.
- The installation screen varies depending on the version of MAC OS X.

1 Close all applications that are running. **2** Insert the CD-ROM.




3 Double-click the CD-ROM icon.

4 Double-click.



5 Click.

6 Read the contents of the License Agreement.



7 Click.




8 Click.




9 Click.
* You cannot change the installation location. Click [Continue].

Depending on the system environment, the [Select a Destination] dialog box may not be displayed. In this case, skip to step **10**.



10 Click.
* [Change Install Location] button may appear, but you cannot change the installation location.



11 Enter.

12 Click.

Depending on the system environment, the [Authenticate] dialog box may not be displayed. In this case, skip to step **13**.




13 Click.


Connecting a USB Cable (For Macintosh)

- Perform the following procedure only when connecting this machine to Macintosh with a USB cable.

- 1 Remove the cap plug.
Remove by pulling the string.



- 2 Connect the cable.
 - Flat end (A): Connect to the USB port on the computer.
 - Square end (B): Connect to the USB port on the machine.



➤ Registering the Printer and Fax P. 27

○ Registering the Printer and Fax (For Macintosh)

To print or send faxes from a Macintosh, you need to register this machine in the Macintosh. The registration method varies depending on the connection type. Select a method according to your environment.
 * The scanning function does not need to be registered.

• When Using Auto IP (Bonjour)
 ⊕ Bonjour Connection P. 27


• When Using a TCP/IP Network
 ⊕ TCP/IP Connection P. 28

• When Connecting with a USB Cable
 ⊕ USB Connection P. 29

○ Bonjour Connection (For Macintosh)


Register the printer and fax respectively following the procedure from 1 to 10.

- 1 Open [System Preferences].
- 2 Click [Print & Fax].
- 3 Click the [+] icon.
 If you are using Mac OS X 10.4.x, click [Print] in the [Print & Fax] dialog box to display the [Print] pane, and then click the [+] icon.



- 4 Select.
- 5 Select.
 Select a printer name for which [Bonjour] is displayed in the [Kind] or [Connection] column.
- 6 Check that the driver which you use is selected.
 If the driver which you use is not automatically selected, select [Select Printer Software], and then select the driver from the list. If you are using Mac OS X 10.5.x, select [Select a driver to use], and then select the driver from the list.

- 7 Click.
- 8 Specify the optional settings as needed.
 Select [Driver] to specify the settings because the setting dialog box is displayed, and then click [OK].



- 9 Check that this machine is added to the [Print & Fax] dialog box.
- 10 Click.

⊕ Checking the Installation Results P. 29


TCP/IP Connection (For Macintosh)

Register the printer and fax respectively following the procedure from 1 to 11.

* You may not use IPv6 with this machine.


- 1 Open [System Preferences].
- 2 Click [Print & Fax].
- 3 Click the [+] icon.

- 4 Select.



- 5 Select.
* [IPP (Internet Printing Protocol)] is not supported.

- 6 Enter the IP address of this machine.



- 8 Click.

- 7 Check that the driver which you use is selected.


If the driver which you use is not automatically selected, select [Select Printer Software], and then select the driver from the list.

If you are using Mac OS X 10.5.x, select [Select a driver to use], and then select the driver from the list.

- 9 Specify the optional settings as needed.

Select [Driver] to specify the settings because the setting dialog box is displayed, and then click [OK].

- 11 Click.




- 10 Check that this machine is added to the [Print & Fax] dialog box.

USB Connection (For Macintosh)

Register the printer and fax respectively following the procedure from 1 to 10.

- 1 Open [System Preferences].
- 2 Click [Print & Fax].
- 3 Click the [+] icon.

4 Select.




- 5 Select. Select a printer name for which [USB] is displayed in the [Kind] or [Connection] column.

- 6 Check that the driver which you use is selected.
If the driver which you use is not automatically selected, select [Select Printer Software], and then select the driver from the list.
If you are using Mac OS X 10.5.x, select [Select a driver to use], and then select the driver from the list.

- 8 Specify the optional settings as needed.
Select [Driver] to specify the settings because the setting dialog box is displayed, and then click [OK].

- 9 Check that this machine is added to the [Print & Fax] dialog box.
- 10 Click.



➤ **Checking the Installation Results P. 29**

Checking the Installation Results (For Macintosh)

With this section, check that the scanner driver is installed correctly.


- You do not need to check the installation results of the printer driver and fax driver. You can use the drivers when the registration of this machine is completed.

- 1 The computer is connected with the scanner.
- 2 Open the Image Capture application of your Mac OS X.
- 3 When [Canon D1300 Series] appears in the following locations, the installation of the driver was successful.
 - Mac OS X 10.5.x
The pull-down menu displayed by clicking [Devices] in the menu bar.
 - Mac OS X 10.6.x
The left list in the window

Using the e-Manual

Page configuration of the e-Manual

When you start the e-Manual, the screen below is displayed.



For Windows

Installing the e-Manual on your computer

- 1 Insert the User Software CD-ROM in your computer.
- 2 Click [Custom Installation].
If CD-ROM Setup does not appear, see "If the top screen does not appear."
- 3 Click [Next].
- 4 Select only the [Manuals] check box.
- 5 Click [Install].
- 6 Click [Yes].
- 7 Click [Install].
- 8 Click [Exit].
- 9 Click [Next].
- 10 When the installation finished, click [Exit].
- 11 To display the e-Manual, double-click the short cut icon [D1300 Series e-Manual] on the desktop.

* ActiveX may block pop-ups in the background. If the e-Manual is not displayed properly, look for an information bar at the top of the page and click the information bar.

If the top screen does not appear

- Windows XP and Server 2003
 1. From the [Start] menu, select [Run].
 2. Enter "D:\Minst.exe", and then click [OK].
 - Windows Vista, 7, and Server 2008
 1. Enter "D:\Minst.exe" in [Start Search] or [Search programs and files] under the [Start] menu.
 2. Press the [ENTER] key on the keyboard.
 - Windows 8 and Server 2012
 1. Right-click the lower-left corner of the screen and select [Run].
 2. Enter "D:\Minst.exe", and then click [OK].
- * The CD-ROM drive name is indicated as "D:" in this manual. The CD-ROM drive name may differ depending on the computer you are using.

Displaying the e-Manual directly from the CD-ROM

- 1 Insert the User Software CD-ROM in your computer.
- 2 Click [Manuals].
- 3 Click [e-Manual].

* Depending on the operating system you are using, a security protection message is displayed. Allow the contents to be displayed.

For Macintosh

Installing the e-Manual on your computer

- 1 Insert the User Software CD-ROM in your computer.
- 2 Open the [Documents] folder.
- 3 Drag and drop the [MF Guide] folder into a location where you want to save it.
- 4 When displaying the installed e-Manual, double-click [index.html] in the saved [MF Guide] folder.

Displaying the e-Manual directly from the CD-ROM

- 1 Insert the User Software CD-ROM in your computer.
- 2 Open the [Documents] → [MF Guide] folders.
- 3 Double-click [index.html].

For more details on the fax, print, and scan functions

See the following Driver Guides or Help.

You can find the driver guides in the following locations on the User Software CD-ROM.


- Canon Fax Driver Guide
User Software CD-ROM → [Documents] → [english] → [FAX] → [Guide] → [index.html]
- Canon MF Printer Driver Guide
User Software CD-ROM → [Documents] → [english] → [Print] → [Guide] → [index.html]
- Canon PS Printer Driver Guide
User Software CD-ROM → [Documents] → [english] → [Print(PS)] → [Guide] → [index.html]
- Canon Scanner Driver Guide
User Software CD-ROM → [Documents] → [english] → [Scan] → [Guide] → [index.html]

Checking the IP Address


- 1 Press [] (Status Monitor/Cancel).



- 2 Press [▲] or [▼] to select, and then press [OK].




- 3 Press [▲] or [▼] to select, and then press [OK].



- 4 Press [▲] or [▼] to select, and then press [OK].



- 5 Check the IP address.



- 6 Press [] (Status Monitor/Cancel) to close the screen.

If the IP address displayed on the screen is between "169.254.1.0 and 169.254.254.255"

This IP address is the one assigned by the AutoIP function. If an IP address other than link-local addresses is set for the computer, set an IP address in the same subnet as the computer (other than link-local addresses) also for this machine manually. This enables the installer to search for this machine.


➔ e-Manual "Setting IPv4 Address"

Check the network operation.


- 1 Start the web browser of a computer which is connected to a network.
- 2 Enter "http://<IP address of the machine>/" in the address field, and then press the [ENTER] key on your keyboard.

The <IP address of the machine> is the address checked in Step 5.

Input Example: <http://192.168.0.215/>



- 3 Check that the screen of the Remote UI is displayed.



When the machine is connected to a switching hub

You may not be able to connect the machine to a network even though your network settings are appropriate. Delaying the machine's network startup time may solve the problem.

➔ e-Manual "Specifying the Wait Time until the Machine Connects to a Network"

When the Remote UI is not displayed

Check the following.

- Whether the computer and hub are connected using a LAN cable
- Whether <Remote UI On/Off> is set to <On>

➔ e-Manual "System Settings"

If You Want to Uninstall the Installed Software

If you do not need the printer driver, fax driver*, scanner driver, or MF Toolbox, you can uninstall them with the following procedure.

* The fax driver can be used only for D1370/D1350.

1. Confirm the following points.

- You must have administrative privileges on the computer
- You should have the installation software (in case you want to re-install the drivers)
- You have closed all applications on your computer

2. Delete the software.


For Windows

* If your machine is connected to a computer via the WSD network, you may not uninstall the drivers or software following the procedures below. Refer to "Uninstalling the Software" in the MF Driver Installation Guide.


For the printer/fax/scanner driver

- 1 Open [Programs and Features].
 - Windows XP
From the [Start] menu, select [Control Panel], and then double-click [Add or Remove Programs].
 - Windows Vista, 7, Server 2003, and Server 2008
1. From the [Start] menu, select [Control Panel].
2. Click [Uninstall a Program] or double-click [Programs and Features].
 - Windows 8 and Server 2012
Right-click the lower-left corner of the screen and select [Programs and Features].


- 2 Click [Canon D1300/MF6700] → [Uninstall].



3 Click.




4 Click.




5 Click.

For MF Toolbox

- 1 Open [Programs and Features].
 - Windows XP
From the [Start] menu, select [Control Panel], and then double-click [Add or Remove Programs].
 - Windows 7
1. From the [Start] menu, select [Control Panel].
2. Click [Uninstall a Program] or double-click [Programs and Features].
 - Windows 8 and Server 2012
Right-click the lower-left corner of the screen and select [Programs and Features].
- 2 Click [Canon MF Toolbox 4.9] → [Uninstall].



3 Click.



4 Click.

For Macintosh


1 If the machine is connected to a computer with a USB cable, disconnect the USB cable.

If you want to delete the Scanner Driver or MF Toolbox, proceed to step 4.

2 Open [System Preferences], and then click [Print & Fax].



3 Select the machine, and then click the [-] icon.



Delete all print queues set from this driver.

4 Start the Mac OS X Finder.

5 From the menu bar, click [Go] → [Go to Folder].

6 Enter the location of the folder below, click [Go], and then delete a file or folder. Drag a file or folder to [Trash] icon on the Dock to delete.

If [Authenticate] dialog box appears, enter the administrator's name and password, and then click [OK].

Software	Location of the folder to enter	Name of the file or folder to delete
Printer driver	/Library/Printers/Canon/	CUPS_MF_Printer
	/Library/Printers/PPDs/Contents/Resources/	CNPZBxxxZB.ppd.gz (xxx may differ depending on the model.)
Fax driver	/Library/Printers/Canon/	CUPSFAQ
	/Library/Printers/PPDs/Contents/Resources/	CNMCxxxFB.ppd.gz (xxx may differ depending on the model.)
Scanner driver/ MF Toolbox	/Applications/	Canon MF Utilities
	/Library/Application Support/Canon/	ScanGear MF
	/Library/Application Support/Canon/	WMCLibrary.framework
	/Library/Application Support/Canon/	WMCReb.plist
	/Library/Image Capture/Devices/*	Canon MFScannerxxx.app* (xxx may differ depending on the model.)
	/Library/Image Capture/TWAIN Data Sources/	Canon xxx.ds Canon xxx USB.ds (xxx may differ depending on the model.)
	/Library/Printers/Canon/	MFScanner

* Max OS X 10.6 or later.

7 Close all windows open.

8 Restart the computer.

Contacting the Service Center

When you have a problem with your machine and you cannot solve it even if you refer to the manuals or online help, please contact our Canon Authorized Service Facilities or the Canon Customer Care Center at 1-800-OK-CANON between the hours of 8:00 A.M. to 8:00 P.M. EST for U.S.A. and 9:00 A.M. to 8:00 P.M. EST for Canada Monday through Friday. Canadian customer support is available on-line at www.canon.ca or by calling 1-800-OK-CANON Monday through Friday from 9:00 A.M. to 8:00 P.M. EST

Disclaimers

The information in this document is subject to change without notice.

CANON INC. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, EITHER EXPRESS OR IMPLIED, EXCEPT AS PROVIDED HEREIN, INCLUDING WITHOUT LIMITATION, THEREOF, WARRANTIES AS TO MARKETABILITY, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OF USE OR NON-INFRINGEMENT. CANON INC. SHALL NOT BE LIABLE FOR ANY DIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM THE USE OF THIS MATERIAL.

Copyright

Copyright CANON INC. 2013

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Canon Inc.

Trademarks

Canon, the Canon logo, and imageCLASS are registered trademarks of Canon Inc. in the United States and may also be trademarks or registered trademarks in other countries.

Bonjour, Finder, Macintosh, Mac OS, and OS X are trademarks or registered trademarks of Apple Inc. in the U.S. and/or other countries.

Microsoft, Windows, Windows Vista and Windows Server are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

This product contains the Universal Font Scaling Technology or UFST® under license from Monotype Imaging, Inc. UFST® is a trademark of Monotype Imaging, Inc. registered in the United States Patent and Trademark Office and may be registered in certain jurisdictions.

UFST: Copyright © 1989 - 1996, 1997, 2003, 2004, 2008, all rights reserved, by Monotype Imaging Inc.

All other product and brand names are registered trademarks, trademarks or service marks of their respective owners.



CANON INC.

30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan

CANON MARKETING JAPAN INC.

16-6, Konan 2-chome, Minato-ku, Tokyo 108-8011, Japan

CANON U.S.A., INC.

One Canon Park, Melville, NY 11747, U.S.A.

CANON EUROPA N.V.

Bovenkerkerweg 59, 1185 XB Amstelveen, The Netherlands

CANON CHINA CO. LTD.

15F Jinbao Building No.89, Jinbao Street, Dongcheng District, Beijing 100005, PRC

CANON SINGAPORE PTE LTD

1 HarbourFront Avenue, #04-01 Keppel Bay Tower, Singapore 098632

CANON AUSTRALIA PTY LTD

1 Thomas Holt Drive, North Ryde, Sydney NSW 2113, Australia

CANON GLOBAL WORLDWIDE SITES

<http://www.canon.com/>

