
















QT56791V03


Canon PIXMA E400 series



5







Black



Color

Black

6



4


1

3


3

4


1




2




3



4



5



5



canon.com/ijsetup




Windows PC



Quick Menu



http://



canon.com/ijsetup



http://

