
Canon



Laser Beam Printer

LASER SHOT



IMPORTANT:

Read this manual carefully before using your printer. Save this manual for future reference.

Remote UI Guide



How This Manual Is Organized

Chapter 1 **Before You Start** Chapter 2 **Using the Remote UI** Chapter 3 Various Functions of the Remote UI Chapter 4 **Appendix**

Notice

 Depending on the printer you are using, the firmware version of the compatible network board varies. If the firmware version is old, the network board may not operate properly.

Download the latest update file from the Canon website to update the firmware. You can also update the firmware using the update file in the "NB-C1 Firmware" folder in the CD-ROM supplied with the printer.

- For details on the procedures for checking the firmware version and updating the firmware in the CD-ROM supplied with the printer, see the README file in the "NB-C1 Firmware" folder.
- To view the manuals in PDF format, Adobe Reader/Adobe Acrobat Reader is required. If Adobe Reader/Adobe Acrobat Reader is not installed on your system, please download it from the Adobe Systems Incorporated website.

[·] Considerable effort has been made to ensure that this manual is free of inaccuracies and omissions. However, as we are constantly improving our products, if you need an exact specification, please contact Canon.

The GIF images on the Remote UI are created using Photoshop by Adobe Systems Incorporated.

Contents

	Preface iii
	How To Use This ManualiiiSymbols Used in This ManualiiiButtons Used in This ManualiiiDisplays Used in This ManualivAbbreviations Used in This Manualiv
	Legal NoticesvTrademarks.vCopyrightvDisclaimers.v
Chapter 1	Before You Start
	Features and Benefits of the Remote UI
Chapter 2	Using the Remote UI
Chapter 3	Starting the Remote UI
Chapter 4	Displaying/Managing the Printer Status (Device Manager)3-2Display Procedure3-2Displaying the Current Status ([Status] Page)3-3Displaying/Changing the Printer Information ([Information] Page)3-7Confirming the Availabilities of the Optional Accessories ([Features] Page)3-8Displaying/Changing the Network Settings ([Network] Page)3-10Displaying the Print Log Page (Job Manager)3-13Displaying/Changing the Links (Support Links)3-14Display Procedure3-14Changing the Links3-15
Chapter 4	
	Index

Preface

Thank you for purchasing this Canon product.

Please read this manual thoroughly before operating the printer in order to familiarize yourself with its capabilities, and to make the most of its many functions. After reading this manual, store it in a safe place for future reference.

How To Use This Manual

Symbols Used in This Manual

The following symbols are used in this manual to indicate operational requirements or clarification.



Indicates operational requirements and restrictions.

Be sure to read these items carefully in order to operate the printer

correctly, and to avoid damage to the printer.



Indicates a clarification of an operation, or contains additional

explanations for a procedure.

Reading these notes is highly recommended.

Buttons Used in This Manual

The following button names are a few examples of how buttons to be pressed are expressed in this manual:

• Buttons on Computer Operation Screen: [Button Name]


Example: [OK]

[Change]

Displays Used in This Manual

Displays used in this manual may differ from those on your computer depending on the system environment.

The buttons which you should press are marked with a _____ as shown below. When multiple buttons can be pressed on the screen shot of computer operation screen, all buttons are marked. Select the button which suits your needs.



Abbreviations Used in This Manual

In this manual, product names and model names are abbreviated as follows:

Microsoft[®] Windows[®] operating system: Windows

Legal Notices

Trademarks

Canon, the Canon logo, LBP, and NetSpot are trademarks of Canon Inc.

Adobe, Adobe Acrobat, Adobe Reader, and Photoshop are trademarks of Adobe Systems Incorporated.

Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.

Ethernet is a trademark of Xerox Corporation.

Other product and company names herein may be the trademarks of their respective owners.

Copyright

Copyright 2006 by Canon Inc. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or by any information storage or retrieval system without the prior written permission of Canon Inc.

Disclaimers

The information in this manual is subject to change without notice.

CANON INC. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, EITHER EXPRESS OR IMPLIED, EXCEPT AS PROVIDED HEREIN, INCLUDING WITHOUT LIMITATION, THEREOF, WARRANTIES AS TO MARKETABILITY, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OF USE OR AGAINST INFRINGEMENT OF ANY PATENT. CANON INC. SHALL NOT BE LIABLE FOR ANY DIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM THE USE OF THIS MATERIAL.

Before You Start



This chapter describes the features of the Remote UI and the system environment in which the Remote UI can be used.

Features and Benefits of the Remote UI	. 1-2
System Requirements	. 1-4

Features and Benefits of the Remote UI

The Remote UI is software that allows you to manage the printer using a web browser. By accessing the printer from the web browser via a network, you can check the printer status or job history, and specify various settings. The Remote UI has the following features.




NOTE

Depending on the printer model or availability of the optional accessories for the printer, the display screen images and the options that can be controlled and specified vary. For more details, see "Chapter 3 Various Functions of the Remote UI".


■ Software other than a web browser is not required.

Because the software required for using the Remote UI (a web server) is preinstalled in this printer, you do not need to have software other than a web browser ready. Running the web browser and specifying the IP address display the Remote UI screen and allows you to use the Remote UI.




■ You can check the printer status from a computer on the network.

The Remote UI allows you to access the printer via a network and display the current status, various information, and job history. You can manage the printer from a remote computer without moving to the printer.



■ You can specify or check various printer settings from a computer.

In the Remote UI, you can specify the network settings and check the printer status. The Administrator mode (The mode to which you need to enter the password to log in) allows only the administrator to perform the settings and operation related to the printer management.



System Requirements

Operation of the Remote UI in the following system environment is guaranteed.

Web Browser Netscape Navigator 4.7 or later

Internet Explorer 4.01SP1 or later

• Operating System An operating system on which the above web

browser can run

Display Resolution: 800 x 600 pixels or more

Display colors: 256 or more



NOTE

Software other than the above one, such as a web server, is not required. (A web server is preinstalled in the printer.)

Using the Remote UI



This chapter describes the procedure for starting the Remote UI and the screen layout.

Starting the Remote UI	. 2-2
Screen Layout of the Remote UI	. 2-4
Logging in as Administrator	.2-6

Starting the Remote UI

Start the Remote UI using a web browser.



IMPORTANT

Depending on the printer you are using, the firmware version of the compatible network board varies. If the firmware version is old, the network board may not operate properly. Download the latest update file from the Canon website to update the firmware.

You can also update the firmware using the update file in the "NB-C1 Firmware" folder in the CD-ROM supplied with the printer.

For details on the procedures for checking the firmware version and updating the firmware in the CD-ROM supplied with the printer, see the README file in the "NB-C1 Firmware" folder.


- Start the web browser.
- 2 Enter the following URL in [Address] or [Location], then press the [ENTER] key on your keyboard.

http://<the IP address of this printer>/

Input Example: http://192.168.0.215/



The screen of the Remote UI is displayed.



(IMPORTANT


- If you are not sure about the IP address of this printer, ask the administrator of the printer.
- If the host name of the printer is registered in the DNS server, you can enter ["hostname"."domain name"] instead of the IP address.
 Example: http://my_printer.xy_dept.company.com/
- If the screen of the Remote UI is not displayed, make sure that the entered IP address or ["hostname"."domain name"] is correct. When the screen of the Remote UI is not displayed even if the entered address is correct, consult your network administrator.
- You cannot connect the computer to the printer via a proxy server. If you are using a proxy server, perform the following settings. (The setting varies depending on the network environment. Consult your network administrator.)
 - On the settings for the proxy server of the web browser, add the IP address of this printer to [Exceptions] (Addresses that do not use the proxy server).
- Configure the web browser so that you can use Cookie.
- If multiple Remote UIs are running simultaneously, the latest setting is effective. It is recommended that only one Remote UI should be running at a time.




Depending on the system environment, the screen of the Remote UI is not displayed even after performing the settings above. In this case, enter "http://<the IP address of this printer>/cab/top.shtml" in [Address] or [Location] to redisplay the screen.

Screen Layout of the Remote UI

When you access to the Remote UI, the following screen is displayed.



■ Operation Buttons







Displays Help on the currently displayed page. Because Help is displayed on an individual window, close the window after using

If the page is scrolled down, moves the scroll box up to the top of the page.

■ Administrator Password/[Log In]/[Log Out]



When you log in as Administrator, enter the password specified in [Device Manager] - the [Information] page - [Security] (See p. 3-8). By logging in as Administrator, you can perform all the operations and settings of the Remote UI. For more details, see "Logging in as Administrator," on p. 2-6.



You can log in as Administrator by entering the administrator password, then clicking this button. When you log in as Administrator, [Log In] changes to [Log Out].



When you are using the Remote UI as Administrator, you can log out by clicking this button. When you log out, [Log Out] changes to [Log In].

■ Image of the Printer (Top Page only)



Displays an image of the printer. The displayed image varies depending on the availability of the paper source option.

Logging in as Administrator


By logging in as Administrator, you can perform all the operations and settings of the Remote UI. When you log in to the Remote UI, you need to enter the password specified in [Security] (See p. 3-8) in the [Information] page in [Device Manager].



NOTE

The password is not specified by default. Log in to the Remote UI without entering a password.

Enter the password, then click [Log In].



Various Functions of the Remote UI 3

This chapter describes the printer information that can be displayed and the options that can be specified in the Remote UI.

Displaying/Managing the Printer Status (Device Manager)	3-2
Display Procedure	3-2
Displaying the Current Status ([Status] Page)	3-3
Displaying/Changing the Printer Information ([Information] Page)	3-7
Confirming the Availabilities of the Optional Accessories ([Features] Page)	3-8
Displaying/Changing the Network Settings ([Network] Page)	3-10
Displaying the Print Log Page (Job Manager)	3-13
Displaying/Changing the Links (Support Links)	3-14
Display Procedure	3-14
Changing the Links	3-15

Displaying/Managing the Printer Status

(Device Manager)

By obtaining information from the printer, you can display the current printer status and printer information in the Remote UI. If you have logged in as Administrator, you can change the settings for the security or network etc. from the Remote UI. [Device Manager] consists of the following four pages.

■ [Status] Page

Displays the current printer status.

■ [Information] Page

Displays the device name and information about the installation site and security.

■ [Features] Page


Display the availability of the optional accessories and [Number of Total Printed Pages].

■ [Network] Page

Displays the settings for the network. You can reset the print server or change the network settings.


Display Procedure

Select any one of [Status], [Information], [Features], or [Network] from the [Device Manager] menu.



Displaying the Current Status ([Status] Page)

Displays the current printer status such as the amount of paper or toner remaining.




① [Device Status]

Displays the current printer status using the indicator and a status message. The colors of the indicator indicate the printer status as follows.

Color of Indicator	Device Status	Remedy
(Green)	Normal (The printer is ready to print)	
(Yellow)	Any remedy is required although this status does not affect the job (A Warning message is being displayed)	Click [Error
(Red)	Cannot print for any reason (An Error message is being displayed)	Information], then follow the displayed directions.
(Red and Blinking)	A problem has occurred and the printer does not operate properly (A service call is being displayed)	unections.


- ② [Error Information]
 When clicked, displays information about the error occurring in the printer.
- ③ [Paper Information]
 Displays information about the paper source.



- (A): The names of each paper source
- (B): The amount of paper remaining in each paper source
- (C): The sizes paper in each paper source
- 4 [Consumables]

Displays information about the consumables.

For a black-and-white printer



(A): Status of the toner cartridge

For a color printer




(A): The amount of toner remaining in each cartridge

Consumables	Display	Status	Remedy
	<available></available>	The printer is ready to print	-
Toner Cartridge (Black-and-white printer)	<replacement Needed Soon></replacement 	The toner cartridge needs to be replaced soon	 You can continue to print. Have ready a new toner cartridge. It is recommended that you replace the toner cartridge before printing a large amount of data (See "User's Guide").
pilitor)	<check Cartridge></check 	A toner cartridge with print quality that cannot be guaranteed or a used toner cartridge that has reached its lifetime is installed.	-
	<install Cartridge></install 	The toner cartridge is not installed	Install the toner cartridge properly.

Consumables	Display	Status	Remedy
	<available></available>	The printer is ready to print	-
	<replacement Needed Soon></replacement 	The toner cartridge needs to be replaced soon	 You can continue to print. Have ready a new toner cartridge. It is recommended that you replace the toner cartridge before printing a large amount of data (See "User's Guide").
Toner Cartridge (Color printer)	<replace Cartridge></replace 	The toner cartridge has reached the end of its life	 When the black toner cartridge has reached the end of its life, the printer stops printing, and you cannot continue the job. When any of the toner cartridges (other than black) has reached the end of its life, you can print only in black and white. Replace the toner cartridge of the indicated color with a new one (See "User's Guide").
	<check Cartridge></check 	Toner cartridges with print quality that cannot be guaranteed or used toner cartridges that have reached their lifetime are installed	Continuing to use these cartridges may cause a malfunction, so replacing these cartridges with new cartridges is recommended (See "User's Guide").
	<install Cartridge></install 	The toner cartridge is not installed	Install the toner cartridge properly.
		The toner cover is open	Close the toner cover firmly.

Displaying/Changing the Printer Information ([Information] Page)


Displays information about the installation site, administrator, display language, etc. If you have logged in as Administrator, you can change the security settings, etc.



- ① [Device Information]
 Displays the general information of the printer. You can display the page that allows you to change the device information by clicking [Change] on the upper right. You can change the device information only when you have logged in as Administrator.
- ② [Language]
 Displays the display language currently being used in the Remote UI. You can display the page that allows you to change the display language by clicking [Change] on the upper right. You can change the language only when you have logged in as Administrator.
- ③ [Security] Displays information about the security settings, such as the settings for the administrator password that the printer has and the access restrictions. You can display the page that allows you to change the security settings by clicking [Change] on the upper right. You can change the security settings only when you have logged in as Administrator. For more details, see "Chapter 3 Managing the Printer in the Network Environment" in Network Guide.
- ④ [Display Log] Displays the [Security Access Log] page that allows you to display, [Save], or [Clear] the obtained security access logs. You can also display the date and time that the print server obtained from the SNTP server, or update the date and time by obtaining them from the SNTP server. You can display the logs only when you have logged in as Administrator. For more details, see "Chapter 3 Managing the Printer in the Network Environment" in Network Guide.

Confirming the Availabilities of the Optional Accessories ([Features] Page)

Displays information about the availabilities of the optional accessories and [Number of Total Printed Pages].




① The icons that indicate the printer information or printer status are displayed.

Icon	Meaning		
A3	Indicates that the printer is capable of printing A3 size paper.		
	Indicates that the printer is capable of color printing.		
Indicates that the printer is capable of 2-sided printing.			

② Information about the maximum printing speed and the total number of printed pages is displayed.

Displaying/Changing the Network Settings ([Network] Page)

Allows you to confirm the network settings. If you have logged in as Administrator, you can change the network settings or reset the print server.



- ① [Network Interface]
 Displays information about the network interface.
- ② [Reset]

Resets the print server. After you change the settings for the network protocols, reset the print server by clicking this button to make the settings effective. You can reset the print server only when you have logged in as Administrator.

(3) [Show Parameter List]

Displays the [Parameter List] page of the printer. You can also initialize the network settings in the [Parameter List] page. You can initialize the network settings only when you have logged in as Administrator. For more details, see "Chapter 3 Managing the Printer in the Network Environment" in Network Guide.



Make sure that the printer is not operating before initializing the network settings. If you initialize the print server while the printer is printing or receiving data, the received data may not be printed properly, or may result in paper jams or damage to the printer.

- ④ [Firmware]
 Displays the name of the current network interface and its version.
- ⑤ [Download Site] Displays the page that allows you to download the firmware. You can download the firmware only when you have logged in as Administrator.



The [Support Links] page (See p. 3-14) allows you to change the link that is displayed by clicking the [Download Site] button.

⑤ [Update Firmware] Updates the firmware. You can update the firmware only when you have logged in as Administrator. For more details, see "Chapter 5 Appendix" in Network Guide.

IMPORTANT

- Depending on the printer you are using, the firmware version of the compatible network board varies. If the firmware version is old, the network board may not operate properly.
 Download the latest update file from the Canon website to update the firmware.
 You can also update the firmware using the update file in the "NB-C1_Firmware" folder in the CD-ROM supplied with the printer.
 - For details on the procedures for checking the firmware version and updating the firmware in the CD-ROM supplied with the printer, see the README file in the "NB-C1_Firmware" folder.
- When you cannot update the firmware properly or want to know details on the procedure for updating the firmware, see the README file supplied with the firmware.
- Make sure that the printer is not operating before updating the firmware. Do not print during the firmware update. Otherwise, the firmware cannot be updated properly.

- 7 [General] Displays the print server name (port name). You can change the print server name only when you have logged in as Administrator.
- (8) [Protocol] Displays the network protocol settings. You can display the page that allows you to change the protocol settings by clicking [Change]. You can change the protocol settings only when you have logged in as Administrator. For more details, see "Chapter 2 Setting Up the Network Environment for Printing" in Network Guide.


IMPORTANT

After changing the network settings, click [Reset] in the [Network] page to reset the print server. If you do not reset the print server, the changed settings cannot be effective.

Displaying the Print Log Page (Job Manager)

You can check the job history in [Job Manager]. Display the job history as follows.

1 Click [Job Manager].






- Up to 32 jobs can be displayed. When the number of the jobs exceeds 32, the print logs are deleted starting from the oldest one.
- A job file name of up to 20 characters can be displayed in [Document Name]. If the number of letters exceeds 20, the letters after the limited number are not displayed, or some letters are not displayed properly. Also, depending on the application, the application name may be added to the beginning of the file name.
- If you turn the printer OFF, all the print logs will be deleted automatically.
- If you print via USB, [Local] is displayed in [Interface Name]. If you print via the network, nothing is displayed in the field.

Displaying/Changing the Links (Support Links)

The links to the sites that provide information about the printer support are supplied in the Remote UI, and you can access the sites from the Remote UI as needed. If you have logged in as Administrator, you can change the links.

Display Procedure

Click [Support Links], then click the link that you want to visit.



The linked website is displayed.



⊘ NOTE

You can display the page that allows you to change the links by clicking [Edit] on the upper right. You can change the links only when you have logged in as Administrator. For more details, see "Changing the Links," on p. 3-15.

Changing the Links

You can display the page that allows you to change the links by clicking [Edit] in the [Support Links] page. You can change [Link], [URL], and [Comments].




NOTE

You can change the links only when you have logged in as Administrator.

1 Clicking [OK] after changing links saves the changed settings.

Clicking [Cancel] displays the original page without changing the settings.





The settings for the [Download Site] field are reflected to the link that is accessed by clicking [Device Manager], then clicking [Download Site] under [Firmware] in the [Network] page (See p. 3-10).

Appendix

ndev	4-3

Α

Administrator, 2-6

C

Changing the Links, 3-15
Confirming the Availabilities of the Optional
Accessories, 3-8
Consumables, 3-4

D

Device Information, 3-8
Device Status, 3-3
Display Log, 3-8
Displaying the Current Status, 3-3
Displaying the Print Log Page (Job Manager), 3-13
Displaying/Changing the Links (Support Links), 3-14
Displaying/Changing the Network Settings, 3-10
Displaying/Changing the Printer Information, 3-7
Displaying/Managing the Printer Status (Device Manager), 3-2
Download Site, 3-11

Ε

Error Information, 3-4

F

Features and Benefits of the Remote UI, 1-2 Features Page, 3-8

Firmware, 3-11

G

General, 3-12

I

Information Page, 3-7

J

Job Manager, 3-13

L

Language, 3-8

N

Network Interface, 3-11 Network Page, 3-10

P

Paper Information, 3-4 Parameter List, 3-11 Protocol, 3-12

R

Reset, 3-11

S

Screen Layout of the Remote UI, 2-4 Security, 3-8 Starting the Remote UI, 2-2 Status Page, 3-3 Support Links, 3-14 System Requirements, 1-4

U

Update Firmware, 3-11

Canon