

Using WFT Utility

You can configure the wireless or wired LAN settings by using WFT Utility. This is convenient if you want to create a wireless or wired LAN settings file when the camera and WFT-E2 II are not nearby.

Starting WFT Utility

- In Windows, click the **[Start]** button, select **[All Programs]** (or **[Programs]**) → **[Canon Utilities]** → **[WFT Utility]**. Then, start up the WFT Utility version corresponding to your model of WFT.
- For Macintosh, open folders in the following order: **[Applications]** → **[Canon Utilities]** → **[WFT Utility]**. Then, start up the WFT Utility version corresponding to your model of WFT.

Using Wireless or Wired LAN Settings


- Click the tabs for the transmitter's **[TCP/IP settings]**, **[FTP settings]**, and **[Wireless LAN settings]** and complete the required settings for a wireless or wired LAN connection. Settings available here are the same as settings on the camera.

The screenshot shows the WFT Utility window with the following elements:


- Title Bar:** WFT - Utility
- Menu Bar:** File, Edit, Help
- Toolbar:** Icons for file operations (new, open, save, print, etc.).
- Settings name:** A text input field.
- Connection Type:** Radio buttons for **Wireless** (selected) and **Wired**.
- Tabs:** Three tabs are visible: **TCP/IP settings** (active and highlighted with a red circle), **FTP settings**, and **Wireless LAN settings**.
- TCP/IP settings section:**
 - IP Addressing:** Radio buttons for **Obtain an IP address automatically(O)** (selected) and **Use the following IP address(S)**. Below are input fields for IP Address(I), Subnet mask(U), and Gateway(W).
 - DNS Settings:** Radio buttons for **Do not use DNS server** (selected), **Obtain DNS server address automatically**, and **Use the following DNS server address**. Below is an input field for DNS server(V).
 - IP Security:** A checkbox labeled **Use IP Security**. If checked, there are input fields for **Destination address** (showing 0.0.0.0) and **Shared Key**.
- Footer:** A checkbox labeled **Protect settings(T)**.

Setting the Wireless LAN Channel

When setting the wireless LAN channel on the [Wireless LAN Settings] tab, first select the version of transmitter used.



Wireless or Wired LAN Settings Files



- Settings files can be used as follows.

Open	Open a settings file saved on the computer or a CF card.
Save	Save the settings file on the computer or a CF card. The [Settings name] is used as the file name. For instructions on applying a settings file on a CF card to the camera, see "Saving and Loading Settings" in the WFT-E2 II instruction manual.
Load settings from camera	Load a settings file on the camera to the computer. The camera and computer must be connected with the USB cable.
Apply settings to camera	Apply the settings file to a camera. The camera and computer must be connected with the USB cable.