Contents of the CD and Structure of the Software

The CD that came with your camera contains software and Software Instruction Manuals.

EOS DIGITAL Solution Disk
- Contains software for use with Canon digital cameras.
- The software on the EOS DIGITAL Solution Disk operates together with the software shown below, centering on ZoomBrowser EX.
  ➡ Shows the shot image flow.
  ⬅ Shows the camera control information from the software.

Download image

Transfer image

② CameraWindow (Software for Communication with the Camera)

- Communicates with the camera to download to your computer images saved on the memory card inside your camera, and can transfer images to ZoomBrowser EX.
- You can display multiple images in a single operation, display images as a list, and download only selected images.
- Images from your card reader can also be downloaded.
- You can set the camera owner's name and the date and time.
- With the EOS-1D Mark II N and EOS 5D, you can set the Picture Style and set the Picture Style file saved on your computer to the camera. Also, with the EOS-1D series cameras, you can register personal functions and various shooting settings in the camera.
- Together with EOS Capture, you can shoot photos remotely.

Download image

Various camera settings

Press the [Shoot] button

Various camera settings

Download image

Transfer image

④ EOS Capture (Remote Shooting Software)

- Together with CameraWindow and ZoomBrowser EX, you can download images you have shot remotely to your computer.
- You can also download the images you have shot by pressing the camera's shutter button to your computer.
- You can control the camera from your computer and perform various settings.

Transfer image

① ZoomBrowser EX (Image Viewing and Editing Software)

- Software recommended if you mainly shoot JPEG images.
- You can display images as a list or display an image in enlarged view on a separate window.
- You can classify images by the date and time they were shot and organize images by setting "Rating" or "Keyword".
- You can search for images by setting conditions.
- You can edit images.
- You can convert and save a JPEG image into a separate image and export for use as wallpaper, etc.

- You can print one image on one sheet of paper or print an index of your images.
- You can attach an image to an e-mail and send it.
- Together with all the software, you can download images from your camera and perform settings for your camera, lay out and print images, process RAW images, shoot photos remotely, and merge images.
- Compatible with color management systems.

Lay out image and print

③ PhotoRecord (Layout Printing Software)

- You can lay out and print images selected in ZoomBrowser EX.
- You can adjust the placement and size of images, select frames, add text, etc. and print.

Select JPEG images and merge

Print image

⑤ PhotoStitch (Image Merging Software)

- You can merge JPEG images selected in ZoomBrowser EX to create panorama images, etc.

Select RAW image and process

⑧ Digital Photo Professional (RAW Image Editing Software)

- Software recommended if you mainly shoot and professionaly edit RAW images.
- You can display and process RAW images at high-speed.
- Real-time image adjustment functions built in.
- Compatible with color management systems.
- Together with EOS Capture, you can shoot photos remotely.

⑥ RAW Image Task (RAW Image Processing Software)

- You can process and display RAW images selected in ZoomBrowser EX and change processing parameters.
- You can set the same processing parameters as the camera or change the conditions.
- You can convert and save a RAW image as a TIFF or JPEG image.
- Compatible with color management systems.

⑦ WIA Driver / TWAIN Driver, PTP WIA Driver / PTP TWAIN Driver

- Software that controls communication between the camera and the computer. The "WIA Driver/PTP WIA Driver" is automatically installed with Windows XP and Windows Me, and the "TWAIN Driver/PTP TWAIN Driver" with Windows 2000 and Windows 98SE.
- Functions as software for downloading JPEG images to your computer if you use the "WIA Driver" alone, or use the "TWAIN Driver" with a TWAIN-compatible software.

Software Instruction Manual
- Contains two PDF Software Instruction Manuals.

EOS DIGITAL Software Instruction Manual

Digital Photo Professional Instruction Manual

- Instruction Manual for ①,②,③,④,⑤,⑥,⑦
- Instruction Manual for ⑧

Copying and Displaying the Instruction Manuals

Copy the PDF Instruction Manuals contained on the CD to your computer.

1 Insert the CD (Software Instruction Manuals) into the CD-ROM drive of your computer.

2 Open the CD.
  - Click [Start] ▶ [My Computer] (in versions other than Windows XP, double-click [My Computer] on the desktop) and then double-click the CD-ROM drive into which you have inserted the CD.

3 Drag and drop the PDF files in the [English] folder to the desktop.
  ➡ The PDF files will be copied to the desktop.

4 Double-click the PDF files.
  ➡ Adobe Reader starts and the Instruction Manuals are displayed.

- You will need Adobe Reader to view the Instruction Manuals. Install Adobe Reader if it is not already installed on your computer.

Installing the Software

- Check that your computer complies with the system requirements for the software and then checkmark the checkboxes ☐ in this guide as you follow the installation procedure.
- The screens used in the examples are from Windows XP.

System Requirements

Software	ZoomBrowser EX, CameraWindow, PhotoRecord, RAW Image Task, EOS Capture, PhotoStitch, WIA Driver / TWAIN Driver		Digital Photo Professional
OS	Windows XP (Home Edition / Professional), Windows Me, Windows 2000, Windows 98SE		Windows XP, Windows 2000
Computer	PC with one of the above OS preinstalled and a USB port as a standard feature or an OHCI-compliant IEEE1394 port * Upgraded machines not supported.		PC with one of the above OS preinstalled * Upgraded machines not supported.
CPU	500MHz Pentium or higher		750MHz Pentium III or higher
RAM	Windows XP, 2000	Minimum 256MB	Minimum 512MB
	Windows Me, 98SE	Minimum 128MB	
Interface	USB 1.1 to 2.0 Hi-Speed or IEEE1394		
Hard disk space	ZoomBrowser EX, CameraWindow, PhotoRecord, RAW Image Task	250MB or more	256MB or more
	EOS Capture	300MB or more	
	PhotoStitch	40MB or more	
	PTP WIA Driver / PTP TWAIN Driver WIA Driver / TWAIN Driver	50MB or more	
Display	Screen resolution: 1024 x 768 pixels or more Color quality: Medium (16 bit) or more		

Installing the Software

1 Check that the camera is not connected to the computer.
- Never connect the camera to your computer before you install the software. The software will not be installed correctly. Connect the camera to your computer in step 12.

2 Start up your computer.
- Exit any programs that are running.

3 Insert the CD (EOS DIGITAL Solution Disk).
➡ The Installer panel appears.

4 Click the [Install] button.
➡ The [Preparing to Install] window appears and after a brief wait, the [Welcome to the InstallShield Wizard for Solution Disk] window appears.

- If the dialog box that prompts you to restart your computer appears, restart your computer. After the computer restarts, the software installation process restarts automatically.

5 Click the [Next] button.

6 Select [Easy Installation] and click the [Next] button.

7 Check the details of the License Agreement and then click the [Yes] button.

8 Click the [Next] button.
➡ Installation begins. It takes approximately 6 to 7 minutes.

9 Select [Yes, I want to restart my computer now] and click the [Finish] button.
➡ The computer restarts.

- If you were unable to successfully install the software or if you connected the camera to your computer before installing the software, see "Troubleshooting" in EOS DIGITAL Software Instruction Manual.

10 Once the computer has restarted, remove the CD.

11 Set the camera's communication mode to [PC connect.].
- This setting is only for EOS DIGITAL REBEL XT/350D DIGITAL and EOS 5D.
- With EOS DIGITAL REBEL XT/350D DIGITAL, set the camera's power switch to <ON>, set [Communication] in menu [⚙2] to [PC connection] and then turn the camera's power switch to <OFF>.
- With EOS 5D, set the camera's power switch to <ON>, set [⚙ Communication] in menu to [PC connect.] and then set the camera's power switch to <OFF>.

How to operate EOS DIGITAL REBEL XT/350D DIGITAL | How to operate EOS 5D

12 Connect the camera to your computer.

Connection Procedure for EOS-1Ds Mark II and EOS-1D Mark II N
- Use the bundled interface cable for connection with the IEEE1394 port to connect your camera to your computer.
- For the EOS-1D Mark II N, attach the cable protector supplied with the camera, and then connect the dedicated cable following the steps below.
- Face the <◇> mark on the plug to the top of the camera and then connect the plug to the camera's <DIGITAL> terminal.
- Connect the cable to the IEEE1394 port on your computer.

- Never use the bundled USB interface cable. The software cannot communicate correctly with your camera and the installation cannot be completed correctly.

Connection Procedure for EOS DIGITAL REBEL XT/350D DIGITAL and EOS 5D
- Use the bundled interface cable to connect your camera to your computer.
- Face the <←→> mark on the plug to the front of the camera and then connect the plug to the camera's <DIGITAL> terminal.
- Connect the cable to the USB port on your computer.

How to operate EOS DIGITAL REBEL XT/350D DIGITAL

How to operate EOS 5D

13 Set the camera's power switch to <ON> to complete installation.

How to turn on EOS-1Ds Mark II, EOS-1D Mark II N | How to turn on EOS DIGITAL REBEL XT/350D DIGITAL

How to turn on EOS 5D

➡ When the pop-up menu as right screen appears and then disappears automatically, the installation is complete.

- For Windows 2000, Me, 98SE, a dialog box such as [Found New Hardware] or [Building driver information database] may appear. If this is the case, installation will be completed when the dialog box disappears.

- Never set the camera's power switch to <OFF> until the pop-up menu, [Found New Hardware] dialog box, or [Building driver information database] dialog box automatically disappears.

- See the respective PDF Software Instruction Manual for information about how to use the software etc.

Contents of the CD and Structure of the Software

The CD that came with your camera contains software and Software Instruction Manuals.

EOS DIGITAL Solution Disk
- Contains software for use with Canon digital cameras.
- The software on the EOS DIGITAL Solution Disk operates together with the software shown below, centering on ImageBrowser.
  ➡ Shows the shot image flow.
  ⬅ Shows the camera control information from the software.

Download image

② CameraWindow (Software for Communication with the Camera)

EOS XXX

Acquire Images | Set to Camera | Remote shooting

Starts to download images

Lets you select and download images

Preferences.... | Quit

- Communicates with the camera to download to your Macintosh images saved on the memory card inside your camera, and can transfer images to ImageBrowser.
- You can download multiple images in a single operation, display images as a list, and download only selected images.

Download image

- Images from your card reader can also be downloaded.
- You can set the camera owner's name and the date and time.
- With the EOS-1D Mark II N and EOS 5D, you can set the Picture Style and set the Picture Style file saved on your Macintosh to the camera. Also, with the EOS-1D series cameras, you can register personal functions and various shooting settings in the camera.
- Together with EOS Capture, you can shoot photos remotely.

Various camera settings

Press the [Shoot] button

Various camera settings

Download image

Transfer image

③ EOS Capture (Remote Shooting Software)

EOS XXX

- Together with CameraWindow and ImageBrowser, you can download images you have shot remotely to your Macintosh.
- You can also download the images you have shot by pressing the camera's shutter button to your Macintosh.
- You can control the camera from your Macintosh and perform various settings.

Transfer image

Transfer image

⑥ Digital Photo Professional (RAW Image Editing Software)

- Software recommended if you mainly shoot and professionally edit RAW images.
- You can display and process RAW images at high-speed.
- Real-time image adjustment functions built in.
- Compatible with color management systems.
- Together with EOS Capture, you can shoot photos remotely.

Transfer image

① ImageBrowser (Image Viewing and Editing Software)

- Software recommended if you mainly shoot JPEG images.
- You can display images as a list or display an image in enlarged view on a separate window.
- You can sort images by the date and time they were shot and organize images by setting "Rating" or "Keyword".
- You can search for images by setting conditions.
- You can edit and rotate images.

- You can convert and save a JPEG image into a separate image and export for use as wallpaper, etc.
- You can print one image on one sheet of paper, lay out and print images or print an index.
- You can attach an image to an e-mail and send it.
- Together with all the software, you can download images from your camera and perform settings for your camera, process RAW images, shoot photos remotely, and merge images.
- Compatible with color management systems.

Print image

Select JPEG images and merge

④ PhotoStitch (Image Merging Software)

Merge Images Shot in Stitch Assist Mode
Click [2. Merge] to merge these images.
For images shot at a 360-degree panorama, click [Arrange], select [360 Degrees] and then click [2. Merge].

1. Selection and Arrangement | 2. Merge | 3. Save

STITCH01.JPG | STITCH02.JPG | STITCH03.JPG | STITCH04.JPG

No. of Images: 4   1024 x 768 True Color

- You can merge JPEG images selected in ImageBrowser to create panorama images, etc.

Select RAW image and process

⑤ RAW Image Task (RAW Image Processing Software)

- You can process and display RAW images selected in ImageBrowser and change processing parameters.
- You can set the same processing parameters as the camera or change the conditions.
- You can convert and save a RAW image as a TIFF or JPEG image.
- Compatible with color management systems.

Software Instruction Manual
- Contains two PDF Software Instruction Manuals.

EOS DIGITAL Software Instruction Manual

Digital Photo Professional Instruction Manual

● Instruction Manual for ①,②,③,④,⑤

● Instruction Manual for ⑥

Copying and Displaying the Instruction Manuals

Copy the PDF Instruction Manuals contained on the CD to your Macintosh.

1 Insert the CD (Software Instruction Manuals) into the CD-ROM drive of your Macintosh.

2 Open the CD.
● Double-click on the CD icon.

3 Drag and drop the PDF files in the [English] folder to the desktop.
➡ The PDF files will be copied to the desktop.

4 Double-click the PDF files.
➡ Adobe Reader starts and the Instruction Manuals are displayed.

English

DPP_M_E.pdf | EDL_M_E.pdf

● You will need Adobe Reader to view the Instruction Manuals. Install Adobe Reader if it is not already installed on your Macintosh.

Installing the Software

- Check that your Macintosh complies with the system requirements for the software and then checkmark the checkboxes ☐ in this guide as you follow the installation procedure.

- The screens used in the examples are from Macintosh OS X 10.3.

System Requirements

Software	ImageBrowser, CameraWindow, RAW Image Task, EOS Capture, PhotoStitch	Digital Photo Professional
OS	Mac OS X 10.2 to 10.4	
Computer	Macintosh with one of the above OS installed and a USB port or FireWire (IEEE1394) port as a standard feature	Macintosh with one of the above OS preinstalled
CPU	PowerPC G3, G4, G5	400MHz G3 or higher
RAM	Minimum 256MB	Minimum 512MB
Interface	USB 1.1 to 2.0 Hi-Speed, FireWire (IEEE1394)	
Hard disk space	ImageBrowser, CameraWindow, RAW Image Task — 250MB or more	256MB or more
	EOS Capture — 550MB or more	
	PhotoStitch — 40MB or more	
Display	Resolution : 1024 x 768 or more Colors : Thousands or more	

- These software programs are not compatible with UFS (Unix File System) formatted disks.

Installing the Software

1 Check that the camera is not connected to Macintosh.

2 Start up your Macintosh.
● Quit any programs that are running.

3 Insert the CD (EOS DIGITAL Solution Disk).
➡ The CD icon appears on the desktop.

4 Start installation.
● Double-click the CD icon ▶ the icon on the right.
➡ The Installer panel appears.

Canon EOS Digital Installer

5 Click the [Install] button.

Canon EOS DIGITAL Solution Disk
Install
Register
Exit

6 Select [Easy Installation] and click the [Next] button.

7 Check the details of the License Agreement and then click the [Agree] button.

CANON SOFTWARE LICENSE AGREEMENT

Disagree | Agree

8 Click the [Next] button.
➡ Installation begins. It takes approximately 5 to 7 minutes.

9 Click the [OK] button.

Installation has finished.

10 Click the [Exit] button.

Canon EOS DIGITAL Solution Disk
Install
Register
Exit

11 Remove the CD.

- See the respective PDF Software Instruction Manual for information about how to use the software etc.