Errata

- Quick Start Guide: Page 6

<Wrong>		<Correct>	
Thickness	Max. 8.5 inches / 25 mm	**Thickness**	Max. 0.98 inches / 25 mm

- User's Guide: "Handling the Original Document" → "■ Original Document Requirements"

<Wrong>		<Correct>	
Thickness	Max. 9.84 inches / 25 mm	**Thickness**	Max. 0.98 inches / 25 mm

- Quick Start Guide: Page 7

- User's Guide: "Handling the Original Document" → "■ Loading Original Documents" → Step 1 → Note

<Wrong>	<Correct>
● You can also scan in originals that are up to 9.84 inches / 25 mm thick, such as books.	● You can also scan in originals that are up to 0.98 inches / 25 mm thick, such as books.

- Quick Start Guide: Page 37

- User's Guide: "Scanning a Photo" → Step2-(2)

- User's Guide: "Printing Area" → "■ A5, A4, B5, 4" x 6", 4" x 8", 5" x 7", 8" x 10", Credit Card, Wide"

<Wrong>	<Correct>
📖 **Note** *- omitted -* When performing automatic duplex printing, Borderless Printing can be specified when one of the following paper sizes is selected; A4 or 4" x 6" / 101.6 x 152.4 mm.	📖 **Note** *- omitted -* When performing automatic duplex printing, Borderless Printing can be specified when one of the following paper sizes is selected; A4 or 5" x 7" / 127.0 x 177.8 mm.

- Quick Start Guide: Page 94

<Wrong>		<Correct>	
Gradation (Input/ Output)	48bit/8bit (Film Scan: 48bit/48 or 24bit) 48bit/24bit (RGB each 16bit/8bit) (Film Scan: 48bit/16 or 8bit)	**Gradation (Input/ Output)**	48bit/8bit (Film Scan: 48bit/16 or 8bit) 48bit/24bit (RGB each 16bit/8bit) (Film Scan: 48bit/48 or 24bit)