



Canon PIXMA E400 series

5






Black




Color

Black

6




4 1




3 3

4


1




2




3



4



5



5



canon.com/ijsetup


Windows PC



Quick Menu



<http://>



canon.com/ijsetup



<http://>

