





Canon

PIXMA E514
series


1




2




3




4




4






5





6









7





8



5



6

94
Color84
Black