





Canon **PIXMA MP237**
series

Model Number: K10379


1



2




2




3



1




2



3




4 1





3 1

4


1




2




3






4




5




6




7




8





9



5



6

811XL
Color
CL-811XL810XL
Black
PG-810XL811
Color
CL-811810
Black
PG-810