

**Canon**

***PowerShot SX740 HS***

Supplementary Information

ENGLISH

© CANON INC. 2018

CT0-D221-A

## Functions and Menu Tables

### Functions Available in Each Shooting Mode

Function	Shooting Mode	M	Av	Tv	P		AUTO				SCN											
Exposure compensation	0 – ±3	○	○	○	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	○	
Movie audio recording		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Flash firing	Auto flash	–	–	–	○	○	○	–	–	–	○	○	–	○	○	○	○	○	○	–	–	
	Flash on	○	○	○	○	○	○	○	○	–	○	○	○	○	○	○	○	○	○	○	–	
	Slow synchro	–	○	–	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
	Flash off	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Av/Tv settings	Av (default: f/4.0)	○	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
	Tv (default: 1/125)	○	–	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
Program shift		–	–	–	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
AE lock/FE lock (linked to metering timer)		○	○	○	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	○	
Focus range	Normal	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Macro	○	○	○	○	–	–	○	–	–	○	○	○	○	○	○	○	○	○	○	–	
	Manual focus	○	○	○	○	–	–	○	–	–	○	○	○	○	○	○	○	○	○	○	–	
On-screen information	Display 1 (default: basic information)	○	○	○	○	○	○	○	–	○	○	○	○	○	○	○	○	○	○	–	○	
	Display 2 (default: basic + details)	○	○	○	○	○	○	○	–	○	○	○	○	○	○	○	○	○	○	–	○	
	No information display	○	○	○	○	○	○	○	–	○	○	○	○	○	○	○	○	○	○	–	○	

○ Available or set automatically. – Not available.

## Quick Control Screen Settings

Function		Shooting Mode										SCN											
		M	Av	Tv	P		AUTO																
AF method	+Tracking	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Tracking AF	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	○	○	○
	Center	○	○	○	○	-	-	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○
AF operation	One-Shot AF	○	○	○	○	○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○
	Servo AF	○	○	○	○	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-
Drive mode	Single shooting	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
	High speed continuous	○	○	○	○	-	○	○	-	○	○	-	○	-	-	-	-	-	-	-	-	-	-
	Low speed continuous	○	○	○	○	-	○	○	-	○	○	-	○	-	-	-	-	-	-	-	-	-	-
	Self-timer:10 sec	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Self-timer:2 sec	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Self-timer:Continuous	2 – 10		○	○	○	○	-	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○
Metering mode	Evaluative metering	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-	○	○	○	○	○	○	-
	Spot metering	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Center-weighted average	○	○	○	○	-	-	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-
Image quality		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
		○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
		○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
		○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
	<b>S</b>	○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-

○ Available or set automatically. - Not available.

Function		Shooting Mode	M	Av	Tv	P		AUTO				SCN												
Movie rec. size	When set to NTSC	3840x2160 29.97 fps (4K)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
		1920x1080 59.94 fps (Full HD)	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
		1920x1080 29.97 fps (Full HD)	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
		1280x720 59.94 fps (HD)	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	When set to PAL	3840x2160 25.00 fps (4K)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○
		1920x1080 50.00 fps (Full HD)	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
		1920x1080 25.00 fps (Full HD)	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
		1280x720 50.00 fps (HD)	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
ISO speed	Auto	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Other	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
White balance	Auto	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Daylight	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	Shade	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	Cloudy	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	Tungsten light	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	White fluorescent light	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	Custom	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
WB correction	B9 – 0 – A9/G9 – 0 – M9	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○		

○ Available or set automatically. – Not available.

Function		Shooting Mode										SCN										
		M	Av	Tv	P		AUTO															
Style settings	Auto	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Standard	○	○	○	○	-	-	-	-	-	-	-	-	○	○	-	○	○	○	○	-	○
	Vivid	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○
	Neutral	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○
	B/W	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○
	Sepia	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○
Auto Lighting Optimizer	Disable	○	○	○	○	-	-	-	-	-	-	-	-	○	○	○	○	○	○	○	○	○
	Low	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○
	Standard	○	○	○	○	○	○	○	○	○	○	○	○	-	-	-	-	-	-	-	-	○
	High	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○
	Disable during man expo	[✓] On		○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		[ ] Off		○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Still img aspect ratio	<b>16:9</b>	○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
	<b>3:2</b>	○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
	<b>4:3</b>	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
	<b>1:1</b>	○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-
Miniature effect movie	Disable	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	5x	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	10x	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
	20x	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
Video snapshot	Video snapshot	Disable		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○	
		Enable		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	○

○ Available or set automatically. – Not available.

Function		Shooting Mode										SCN												
		M	Av	Tv	P		AUTO																	
Brightness	Range: ±2	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	Range: ±3	-	-	-	-	-	-	○	-	○	○	○	○	-	-	-	-	-	-	-	-	○	-	
Shooting mode		-	-	-	-	-	-	-	-	-	○	○	○	○	○	○	○	○	○	○	○	○	-	
Filter effect level	When set to [Smooth skin]	Smooth skin effect	Low	-	-	-	-	-	-	○	-	-	○	-	-	-	-	-	-	-	-	-	-	
			Medium	-	-	-	-	-	-	○	-	-	○	-	-	-	-	-	-	-	-	-	-	-
			High	-	-	-	-	-	-	○	-	-	○	-	-	-	-	-	-	-	-	-	-	-
	When set to [Background blur]	Background blur	Auto	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	
			Off	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	When set to [Food]	Color tone	Standard	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
			2 cool levels/2 warm levels	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	When set to [Grainy B/W]	Contrast	Low	-	-	-	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	
			Standard	-	-	-	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-
			High	-	-	-	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-
	When set to [Soft focus]	Soft focus	Low	-	-	-	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	
			Standard	-	-	-	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-
High			-	-	-	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	

○ Available or set automatically. – Not available.

Function				Shooting Mode										SCN										
				M	Av	Tv	P		AUTO															
Filter effect level	When set to [Fish-eye effect]	Effect	Low	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
			Standard	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
			High	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	When set to [Art bold effect]	Effect	Low	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
			Standard	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
			High	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	When set to [Water painting effect]	Color density	Light	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
			Standard	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
			Deep	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	When set to [Toy camera effect]	Color tone	Cool tone	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
			Standard	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
			Warm tone	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

O Available or set automatically. - Not available.

## Shooting Menu Settings

Function		Shooting Mode										SCN									
		M	Av	Tv	P		AUTO														
Image quality		See "Quick Control Screen Settings" (📖3).																			
Still img aspect ratio		See "Quick Control Screen Settings" (📖3).																			
Image review	Off	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	2 sec.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	4 sec.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	8 sec.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Hold	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Flash settings	Flash mode	Auto	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
		Manual	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Flash exp. comp	0	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
		±2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Flash output	Minimum	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
		Medium	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
		Maximum	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Red-eye lamp	On	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
		Off	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Safety FE	On	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Off		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Drive mode		See "Quick Control Screen Settings" (📖3).																			

○ Available or set automatically. – Not available.



Function		Shooting Mode										SCN									
		M	Av	Tv	P		AUTO														
Date stamp	Off	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Date	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Date & time	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Exposure compensation		See "Functions Available in Each Shooting Mode" (📖2).																			
ISO speed		See "Quick Control Screen Settings" (📖3).																			
Auto Lighting Optimizer		See "Quick Control Screen Settings" (📖3).																			
Metering mode		See "Quick Control Screen Settings" (📖3).																			
Metering timer	4 sec.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	8 sec.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	16 sec.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	30 sec.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	1 min.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	3 min.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Safety shift	Disable	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Enable	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
White balance		See "Quick Control Screen Settings" (📖3).																			
Custom White Balance		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
WB correction		See "Quick Control Screen Settings" (📖3).																			
Style settings		See "Quick Control Screen Settings" (📖3).																			
AF operation		See "Quick Control Screen Settings" (📖3).																			
AF method		See "Quick Control Screen Settings" (📖3).																			

○ Available or set automatically. – Not available.

Function		Shooting Mode										SCN											
		M	Av	Tv	P		AUTO																
AF frame size	Normal	○	○	○	○	-	-	○	-	○	○	○	○	○	○	○	○	○	○	○	-	○	
	Small	○	○	○	○	-	-	○	-	-	○	○	○	○	○	-	○	○	○	-	-	-	
Continuous AF	Enable	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	-	-	
	Disable	○	○	○	○	-	-	○	○	-	○	○	○	○	○	○	○	○	○	○	○	-	
AF-assist beam firing	Enable	○	○	○	○	○	○	○	○	-	○	○	○	○	○	○	○	○	○	○	-	-	
	Disable	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
MF peaking settings	Peaking	On	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	-	○	
		Off	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○
	Level	Low	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○
		High	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○
	Color	Red	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○
		Yellow	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○
Blue		○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○	
Safety MF	On	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○	
	Off	○	○	○	○	-	-	○	-	-	○	○	○	○	○	○	○	○	○	○	-	○	
Grid display	Off	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	3x3	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	3x3+diag	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	



















○ Available or set automatically. - Not available.

Function			Shooting Mode										SCN										
			M	Av	Tv	P		AUTO															
IS settings	IS mode	Off	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
		On	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
		Shoot only	○	○	○	○	–	–	○	○	○	○	○	○	○	○	○	○	○	○	○	○	–
	Dynamic IS	Low	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
		Standard	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
		High	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	○	○
Auto level	Enable	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Disable	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Digital zoom	Standard	○	○	○	○	○	○	–	–	○	○	–	–	–	–	–	–	–	–	○	○		
	Off	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	1.6x	○	○	○	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
	2.0x	○	○	○	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
Digest type	Include stills	–	–	–	–	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
	No stills	–	–	–	–	○	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	
Display area	Large	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Medium	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Small	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Auto zoom	Off	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Auto	–	○	○	○	○	○	○	○	○	○	○	○	○	○	–	○	○	○	–	–	○	
	Face	–	○	○	○	○	○	○	○	○	○	○	○	○	○	–	○	○	○	–	–	○	
	Upper body	–	○	○	○	○	○	○	○	○	○	○	○	○	○	–	○	○	○	–	–	○	
	Whole body	–	○	○	○	○	○	○	○	○	○	○	○	○	○	–	○	○	○	–	–	○	
	Manual	–	○	○	○	○	○	○	○	○	○	○	○	○	○	–	○	○	○	–	–	○	

○ Available or set automatically. – Not available.

Function		Shooting Mode										SCN												
		M	Av	Tv	P		AUTO																	
Movie rec. size		See "Quick Control Screen Settings" (p.3).																						
Wind filter	Auto	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
	Off	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>		
Attenuator	Auto	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
	On	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>		
	Off	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
Auto slow shutter	Disable	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>		
	Enable	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Video snapshot	Video snapshot	Disable	See "Quick Control Screen Settings" (p.3).																					
		Enable	See "Quick Control Screen Settings" (p.3).																					
	Album settings	Create a new album	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
		Add to existing album	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
	Playback time	4 sec.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
		6 sec.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
		8 sec.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
	Playback effect	1/2x speed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
		1x speed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
		2x speed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
	Show confirm msg	Enable	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>	
Disable		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	<input type="radio"/>		

O Available or set automatically. – Not available.

Function			Shooting Mode										SCN												
			M	Av	Tv	P		AUTO																	
Time-lapse movie	Time-lapse	Disable	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O	
		Scene 1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
		Scene 2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
		Scene 3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
	Interval/shots		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O	
	Movie rec. size	 FHD	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
		 4K	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
	Auto exposure	Fixed 1st frame	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
		Each frame	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
	Screen auto off	Disable	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
		Enable	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
	Beep as img taken	Enable	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O
		Disable	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	O

O Available or set automatically. – Not available.