



ENGLISH

繁體中文

한국어

ภาษาไทย


BAHASA INDONESIA

TIẾNG VIỆT


Canon

E560 series


1




2




2



3




4




XXXXXXXX

3



1




2



3



4 1




3 1

© CANON INC. 2024



PRINTED IN XXXXXXXX

4


1



2



3



Lower the lever.


將控制杆往下壓。

레버를 아래로 내림.



ลดคานลง

Turunkan tuas.



Hạ thấp đòn bẩy xuống.





4



5



6



7 Repeat 3 to 6 to install the other FINE Cartridge.


重複 3 到 6 安裝其他 FINE 墨盒。

3 ~ 6 를 반복하여 다른 FINE 카트리지를 설치합니다.


ทำซ้ำ 3 ถึง 6 เพื่อติดตั้งคาร์ทริด FINE อื่น ๆ

Ulangi 3 sampai 6 untuk memasang Kartrij FINE lain.


Lặp lại 3 đến 6 để lắp đặt FINE Cartridge khác.



8



9



Flashing.


閃爍。

깜박이는 상태.

กระพริบ

Berkedip.

Nhấp nháy.



Lighting.

常亮。

켜진 상태.


สว่าง

Menyala.


Đèn sáng.

5


1




2




3




4




5



6



6



canon.com/ijsetup



Manuals



説明書

설명서

คู่มือ

Manual

Sách hướng dẫn



canon.com/ijsetup

