

## Support for the Optional LM-V2 LCD Monitor

After updating the camera's firmware to ver. 1.0.6.1.00, you will be able to use the optional LM-V2 LCD Monitor. Using the optional LA-V2 LCD Attachment Unit, you will be able to attach the LM-V2 to the handle unit or to the camera's body in a similar way as when using the LM-V1. For details about attaching and adjusting the LCD monitor, refer to the C200 / C200B Instruction Manual.

[PDF](#) *Attaching and Removing the LM-V1 LCD Monitor*; [PDF](#) *Preparing the Camera*

The following settings/options will be added to the menus or changed after the firmware version update.

### Assignable Functions

Function name	Description	CAMERA	MEDIA
[LCD LM-V2 Setup]	Opens the [ Monitoring Setup] menu.	●	●

### [ Monitoring Setup] menu

These settings are added as menu page [2](#).

Menu item	Setting options and additional information
<a href="#">2</a>	
[LCD LM-V2 Brightness]	-99 to +99 ( <b>±0</b> )
[LCD LM-V2 Contrast]	-99 to +99 ( <b>±0</b> )
[LCD LM-V2 Color]	-20 to +20 ( <b>±0</b> )
[LCD LM-V2 Sharpness]	1 to 4 ( <b>2</b> )
[LCD LM-V2 Luminance]	[+2], [+1], [ <b>Normal</b> ]
	[LCD LM-V2] settings are used to adjust, respectively, the brightness, contrast, color saturation, sharpness and luminance of an optional LM-V2 LCD Monitor.

### [ Assignable Buttons] menu

The settings on page [4](#) change as follows.

Menu item	Setting options and additional information
<a href="#">4</a>	
[LCD LM-V1/V2: 1] and [LCD LM-V1/V2: 2]	1: [ <b>FUNC</b> ], 2: [ <b>Display</b> ] These settings apply equally to the assignable buttons on either model. A new assignable function [LCD LM-V2 Setup] is also available.

### [ System Setup] menu

Menu item	Setting options and additional information
<a href="#">5</a>	
[Touch Screen Response]	[ <b>Normal</b> ], [Low] This setting is available only when an LM-V1 or LM-V2 LCD Monitor is connected to the camera and applies equally to either model.