



Unpack the Machine


- Please confirm the included items against the illustration printed on the lid of the packing box.
- A USB cable is necessary to connect the machine with your computer.



When cleaning the exterior of the machine, use a soft cloth to wipe it gently. For details, refer to "Cleaning Your Machine" in the Quick Start Guide.

1 Prepare the Machine


Important
When moving the machine, carry the machine at both ends as shown below. Do not lift the machine by grasping the Paper Support Extension.




1 Place the machine on a flat and horizontal surface, and do not place any objects in front of the machine.

Remove all the shipping tapes and protective material on the outside of the machine.


Then open the Paper Output Tray.



2 Lift the Scanning Unit (Printer Cover), and pull the Scanning Unit Support down into place.




3 Remove the protective material on the right side.




Caution
Before turning on the machine, remove all of the shipping tapes.

4 Lift the Scanning Unit (Printer Cover) slightly to set the Scanning Unit Support back to its original position, and then gently close the Scanning Unit (Printer Cover).




5 Plug the power cord in the back of the machine and connect the other end to the wall outlet.




Important
Make sure that the Document Cover is closed.

Note
Do NOT connect the USB cable at this stage.


6 Press the ON/OFF button to turn on the machine. The machine will initialize. Wait until the Power lamp stops flashing and remains lit green.



7 Lift the Scanning Unit (Printer Cover), and pull the Scanning Unit Support down into place. The FINE Cartridge Holder automatically moves to the left.




8 Write down the serial number located inside the machine. You will need this to register your product.




2 Install the FINE Cartridges

1 Remove the Black FINE Cartridge from its box.




2 Remove the protective tape gently.




Important
• Do not touch the electrical contacts or Print Head Nozzles on a FINE Cartridge. The machine may not print out properly if you touch it.
• Do not reattach the protective tape once you have removed it.
• Be careful not to stain your hands or surrounding work area with ink on the removed protective tape.

3 Insert the Black FINE Cartridge slightly slanted into the left slot **B**.




4 Push up the FINE Cartridge until it clicks into place.


Important
For correct machine operation, make sure the FINE Cartridge is securely inserted.




5 Repeat the procedure for the Color FINE Cartridge, inserting it into the right slot **C**.



6 Lift the Scanning Unit (Printer Cover) slightly to set the Scanning Unit Support back to its original position, and then gently close the Scanning Unit (Printer Cover).



Important
Once you have installed the FINE Cartridges, the LED will flash green. Wait until the LED stops flashing and displays 1. It takes about one to two minutes.



Hardware setup is complete.



Windows® Software Installation

Windows

Note

- The screens below refer to Windows Vista™ operating system Ultimate Edition (hereafter referred to as "Windows Vista") installation. Screens may vary depending on the operating system you are using.
- Log into a user account with the administrator privilege.
- Before installing the software, disable all anti-virus programs and automatically loading programs.
- A message asking for your confirmation to restart your computer may appear during the installation process. If this message is displayed, follow the on-screen instructions and click **OK**. The installation resumes from where it left off when your computer has been restarted.

1 Be sure to **TURN THE MACHINE OFF** before continuing.

- Press the **ON/OFF** button.
- Make sure that the **Power** lamp stops flashing.

2 Turn the computer on and start Windows.

Important

If the **Found New Hardware** or **Found New Hardware Wizard** screen appears automatically, remove the USB cable connected to your computer. Click **Cancel** to quit the screen. In Windows Vista, the screen may close automatically when the USB cable is unplugged. Then turn off the machine and proceed from step **3** to install the software.



3 Insert the Setup CD-ROM. The setup program should run automatically.

In Windows Vista, go to Step **4**. In Windows XP and Windows 2000, go to Step **6**.

4 If the **AutoPlay** screen appears, click **Run Msetup4.exe**.



5 If the **User Account Control** screen appears, click **Continue**. If the same screen reappears in subsequent steps, click **Continue**.



6 When the main menu appears, click **Easy Install**.

The MP Drivers, On-screen Manuals, and application software are installed automatically.



Note

If you want to select particular items to install, click **Custom Install** and follow the on-screen instructions to proceed the installation.

7 When the list of applications to install appears, confirm the contents, click **Install**.

Note


Move the cursor over items to display explanations of each application.

8 Read the License Agreement carefully and click **Yes**. The software installation screen may appear during the installation process. Follow the on-screen instructions to install the software.

9 When the **Printer Connection** screen appears, connect one end of the USB cable to the computer, the other to the machine, then **TURN THE MACHINE ON**. The MP Drivers will begin identifying the printer port being used.

Important

If you cannot go to the next procedure after three minutes, refer to "Troubleshooting" instructions in the *User's Guide* on-screen manual.



10 When the **Print Head Alignment Recommended** screen appears, click **Next**.

11 When the **Setup Complete** screen appears, click **Next**.



12 When the **User Registration** screen appears, click **Next**.

Note

To register later, click **Cancel** and go to Step **13**. After software installation is complete, double-click on the desktop.

Follow on-screen instructions to register your product. You will need your product serial number, which is located on the inside of the machine. See Step 1- **3** on the front page.

13 When the **PIXMA Extended Survey Program** screen appears, confirm the message. We would appreciate it if you would take part in this program regarding the use of Canon printers. If you can agree, click **Agree**.

14 When the **Installation completed successfully** screen appears, click **Exit**.

If **Restart** is displayed, make sure that the **Restart the system now (recommended)** check box is selected, then click **Restart**.

Note

If straight lines are misaligned or print quality is not satisfactory after installing the MP Drivers, you may need to align the Print Head. Refer to "Aligning the Print Head" in the *Quick Start Guide*.

Software installation is now complete.

Macintosh® Software Installation

Macintosh


Note

- Since Mac® OS 9, Mac OS X Classic environments, or Mac OS X v.10.2.7 or earlier are not supported, do not connect the machine to these.
- The screens below refer to Mac OS X v.10.4.x installation. Screens may vary depending on the operating system you are using.
- Log on as an Administrator.
- Before installing the software, disable all anti-virus programs and automatically loading programs.

1 Connect one end of the USB cable to the computer and the other to the machine.

Note

Make sure the machine is turned on.



2 Turn on your Mac and insert the Setup CD-ROM.

Note


If the CD-ROM folder does not open automatically, double-click the CD-ROM icon on the desktop.

3 Double-click the **Setup** icon.

4 When the **Authenticate** screen appears, enter your administrator name and password. Click **OK**. If you do not know your administrator name or password, click , then follow the on-screen instructions.

5 When the main menu appears, click **Easy Install**.

The MP Drivers, On-screen Manuals, and application software are installed automatically.



Note

If you want to select particular items to install, click **Custom Install** and follow the on-screen instructions to proceed the installation.

6 When the list of applications to install appears, confirm the contents, then click **Install**.

Note

Move the cursor over items to display explanations of each application.

7 Read the License Agreement carefully and click **Yes**. The software installation screen may appear during the installation process. Follow the on-screen instructions to install the software.

8 When the **Print Head Alignment Recommended** screen appears, click **Next**.

9 When the **Setup Complete** screen appears, click **Next**.

10 When the **User Registration** screen appears, click **Next**.

Note

To register later, click **Cancel** and go to Step **11**. After software installation is complete, double-click on the desktop.

Follow on-screen instructions to register your product. You will need your product serial number, which is located on the inside of the machine. See Step 1- **3** on the front page.

11 When the **Installation completed successfully** screen appears, click **Restart**.



The system is restarted automatically.

When using Mac OS X v.10.2.8 to v.10.3.3:

Restarting the computer while connected to the machine may cause the machine not to be detected. To resolve this, either unplug the USB cable then plug it back in again, or turn the machine off then back on again.

Note

- When using Mac OS X v.10.2.8 to v.10.3.x, before using the Operation Panel on the machine to save originals scanned from the Platen Glass to the computer, it is necessary to select **MP Navigator EX 1.0** or **MP Navigator EX 1** as the launch application on Image Capture under **Applications**. For details, refer to "Scanning Images" in the *User's Guide* on-screen manual.
- If straight lines are misaligned or print quality is not satisfactory after installing the MP Drivers, you may need to align the Print Head. Refer to "Aligning the Print Head" in the *Quick Start Guide*.

Software installation is now complete.