PUB. DIE-0557-000A



# CR-X500 1A CR-X500 2A

**Remote Camera** 

Instruction Manual

# Important Safety and Handling Instructions

## Safety instructions

Be sure to read these instructions in order to operate the product safely. Follow these instructions to prevent injury or harm to the operator of the product or others.

# In Case of Emergency (troubleshooting under abnormal situations)

If any of the following situations occurs, **immediately unplug** the power cable from the power outlet.

- If smoke, strange smells or abnormal noises are detected.
- If the product fell and was damaged.
- If foreign objects (metallic objects, liquids, etc.) get inside the product.

Continuing to use the product under such circumstances may cause fire or electric shock. Contact a Canon sales representative as soon as possible.

# 

Denotes the risk of serious injury or death.

#### Transportation/Installation

• Do not install the product in a location where there is the risk of ignition or combustion.

Installing the product in a location where flammable gases are produced or concentrated may cause ignition and result in fire.

- Securely attach any parts to the product, firmly tightening the necessary screws according to the instruction manual. If the product is not firmly secured or if screws are loose, the product may topple over or fall down, resulting in injury and accidents.
- When installing the product in an elevated location, make sure to take appropriate measures in advance to prevent the equipment and parts from falling off.

Equipment falling down may cause serious injury.

#### Power supply

- Ensure the power cable is fully inserted into the power outlet.
- Do not handle the power cable or plug with wet hands.
- Do not leave the product plugged in for extended periods of time in locations exposed to high levels of dust, moisture or oily smoke.

Doing so may cause insulation failures and even fires.

- Periodically wipe the power cable, power outlet and terminals with a dry cloth to remove dust buildup.
- Make sure to turn off the product before connecting/ disconnecting power cables.
- Do not use excessive force on the power cable. A damaged power cable can lead to fire or electric shock.
- AC power model only:
  - Avoid the use of multi-socket adapters and extension cords.
  - Do not unplug the product by pulling the power cord.
  - Always keep the power plug easily accessible. Do not place obstructing objects around it.


- DC power model only:
  - Make sure to use a power cable that is suitable for the installation conditions (authorized products, environmental regulations) and conforms to the product's power specifications. Using an unsuitable power cable may cause electric shock and fire.
  - Remove the screws together with the power cable.

#### Handling

- Do not allow liquids or foreign matter inside the unit.
- Do not expose the product to strong shocks or vibration.

#### Maintenance and Inspection

- Unplug the power cable from the power outlet before cleaning it using a dry cloth.
   Cleaning the power cable when the product is turned on or using a wet cloth may cause electric shock.
- Do not use organic solvents such as alcohol, benzene or paint thinner to clean the product.
- Do not disassemble or modify the product.
  - There are exposed electrodes and gears inside the product. Contact with such parts may cause injury or electric shock.
  - Foreign objects or dust entering into the product may cause malfunctions.
  - In surroundings exposed to high temperatures and humidity, humid air entering inside the product may cause malfunctions and condensation.



#### Transportation/Installation

- Do not install the product on an unstable surface or in locations exposed to severe vibration.
   This may cause the product to topple over or fall down, resulting in injury.
- Do not install the product in locations directly exposed to salt water or where corrosive gases or oily smoke are present. Contact with such substances may corrode and degrade the mountings, causing the product to fall down and cause injury.
- When transporting the robotic camera head, always use two people to lift it, firmly grabbing the handles.
   Dropping the product may damage it and cause injury and accidents.

#### Handling

• Make sure there are no people within the product's operating range.

The product hitting a person may cause injury.

• Inspect mountings regularly (every six months to one year) to ensure they are securely tightened.

## **Handling Precautions**

• Do not install the product in a location exposed to high temperatures.

This may cause malfunctions.

- Do not turn the camera head's rotating parts forcibly by hand.
  - Forcibly turning the rotating parts may damage these parts.

Always use the control device to operate the product's rotating parts.

- When using a model that has an AC power source, remove the power plug to cut off power to the AC line.
   All devices are fitted with a noise filter; so, there is still an electric current in the AC line even if the power switch is
- turned off.
  Do not install the product in a position where the lens is pointed at intense light sources, such as the sun on a sunny day, lasers and other intense artificial lights.

Doing so may damage the image sensor or the camera's internal components.

## Disclaimers

- 1 Canon shall bear no responsibility for damage resulting from improper operation of this product by the customer.
- 2 Regarding this product's quality, functionality or instruction manual, Canon shall make no guarantees about its marketability or suitability for the customer's purpose. Moreover, Canon shall not be liable for any damage, direct or incidental, that results from using the product for the customer's purpose.
- 3 Canon shall bear no responsibility for any loss, damage, direct or indirect, or any incidental loss, damage (including filming expenses and loss of filming earnings) arising out of the failure of this product or arising out of the use of this product.

- Beware of freezing conditions. The product does not have a freeze-proof structure so take precautions when installing it in locations that may freeze. The product may not operate correctly if frozen.
- Return the housing to the horizontal position before transporting the unit.
   To avoid damage during transportation, always carry the unit in the supplied box.
- If the supplied box is not available, contact your retailer or Canon sales representative before purchasing packaging materials.
  - Some boxes and packaging materials use adhesive or other substances that could damage the product.

- 4 The product specifications, configuration, and appearance are subject to change without prior notice.
- 5 For further information on repairs, maintenance, or adjustments not mentioned in this instruction manual, contact a Canon sales representative.
- 6 Note that Canon may be unable to undertake servicing or repair of a product if it is modified without consulting Canon or your Canon sales representative.

# Table of Contents

Important Safety and Handling Instructions	2
Safety instructions	2
Handling Precautions	3
Disclaimers	3
1. Introduction	5
About this Manual	5
Components	5
Overview	6
System connections	6
Short distance transmission	6
2. Installation	7
Handling of the unit	7
Fixing of the unit	7
Attaching the washer and microphone (optional)	7
Installing a lightning rod	8
Attaching a safety wire	8
Waterproofing the receptacle unit	8
Connections	9
3. Details of operation and functions	10
3. Details of operation and functions	
-	10
Operation precautions	<b>10</b> 10
Operation precautions Panning range	<b>10</b> 
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix Adjusting the image quality	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix Adjusting the image quality Available Custom Picture Settings	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix Adjusting the image quality Available Custom Picture Settings 4. Additional information	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix Adjusting the image quality Available Custom Picture Settings <b>4. Additional information</b> Troubleshooting	
Operation precautions	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix Adjusting the image quality Available Custom Picture Settings <b>4. Additional information</b> Troubleshooting Specifications Camera unit	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix Adjusting the image quality Adjusting the image quality Available Custom Picture Settings <b>4. Additional information</b> Troubleshooting Specifications Camera unit Head unit (Pan-tilt section)	
Operation precautions         Panning range         Tilting range         Control connectors         Pan-tilt head, housing, lens, and camera operation         Custom picture settings         Selecting custom picture settings         Selecting the gamma curve, color space and color matrix         Adjusting the image quality.         Available Custom Picture Settings <b>4. Additional information</b> Troubleshooting         Specifications         Camera unit.         Head unit (Pan-tilt section)         External View	
Operation precautions Panning range Tilting range Control connectors Pan-tilt head, housing, lens, and camera operation Custom picture settings Selecting custom picture settings Selecting the gamma curve, color space and color matrix Adjusting the image quality Adjusting the image quality Available Custom Picture Settings <b>4. Additional information</b> Troubleshooting Specifications Camera unit Head unit (Pan-tilt section)	10 10 10 10 10 10 10 10 10 10

# About this Manual

Thank you for purchasing the Canon CR-X500 1A/CR-X500 2A. Please read this manual carefully before you use the remote camera and retain it for future reference. Should the remote camera fail to operate correctly, refer to *Troubleshooting* ( $\square$  19).

## Conventions Used in this Manual

- IMPORTANT: Precautions related to the remote camera's operation.
- (i)NOTES: Additional topics that complement the basic operating procedures.
- D: Reference page number.
- Names of products and companies mentioned in this manual may be trademarks or registered trademarks of their respective companies.

# Components


Before using this product, make sure that the package contains the items listed below. If you find anything missing, please contact the dealer from whom you bought the product. For details on optional products, refer to the catalog, or contact your Canon dealer or your Canon sales representative.

Unit name	Q'ty
Main unit	1
Waterproof tube (RohrFlex) RF-36 FLEXA	1
Control connector (for RS-422) EPRC05-P12F	1
Ferrite core E04SR241336A	3
Important Information	1


#### 


• No power cord is supplied for the pan-tilt head. Use the power cord that has regulatory agency approval for the specific country in which it is used.

# Overview



# System connections






 $^{\star}$  Use the supplied control connector (for RS-422).

For further information, please contact your Canon dealer or your Canon sales representative.

# 2

# Handling of the unit


When carrying the unit, hold the unit by its handle. Be careful not to rotate the housing and head forcibly.



# Fixing of the unit

The dimensions for drilling the holes in the floor are shown below.

If necessary, prepare  $\phi$  185 to 200 steel spacers to prevent interference between the floor and the cables. Use steel bolts with a length that enables a screw-in depth of 12 mm or more into the floor, and fix the unit securely to a strong floor surface. Use a level to check that the floor and the head unit are horizontal.



# Attaching the washer and microphone (optional)


To also install a washer or microphone, please obtain the mounting jigs (not included). For more information about optional products, please contact your Canon dealer or your Canon sales representative.

# Installing a lightning rod

If precautions need to be taken against lightning in case the system is to be installed on a hill-top or other such location, provide a lightning rod as shown in the figure.

Make sure that the system will not touch the lightning rod when the camera is panned.

In the case of a permanent installation, safety is further enhanced by providing a lightning-proof transformer for the system's power supply.




# Attaching a safety wire

In case a safety wire is necessary for the pan-tilt head, make sure to attach the wire to the handle section. When attaching the wires, be careful that nothing blocks operation of the pan-tilt head.


# Waterproofing the receptacle unit

Inspect the waterproof connector for looseness. After passing each cable through the waterproof tube and the waterproof unit, insert the waterproof tube all the way into the waterproof connector until its tip touches the end and secure it in place. Put the end of the waterproof tube in a safe place so that water, dust and moisture do not enter. Also, do not seal the end of the waterproof tube so as to mitigate a pressure rise inside of the product caused by the temperature change. Connect each cable to the receptacle unit of the main unit, and then secure the waterproof unit to the pan-tilt head using the supplied mounting bolts (x4). Clamp the cables at appropriate intervals.



# Connections

When connecting each cable to the MIC terminal, the WASHER terminal, and AUX terminal, be sure to always use the ferrite core supplied with this product.



# Details of operation and functions


# **Operation precautions**

#### 

• The panning and tilting ranges may be off by about 5% due to zoom fluctuations caused by focusing, mounting errors of the pantilt head, etc. Check the actual panning and tilting ranges before proceeding to set to the subject.


## Panning range

The panning range extends 170 degrees to the left and right. This yields a turning range with a 620 mm diameter which should be taken into account when selecting the installation location.



## **Tilting range**


The tilting range is approximately 430 mm when the pan-tilt head is inclined upward at an angle of 30 degrees and downward at an angle of 50 degrees: this should be taken into account when selecting the installation location.



#### 

• Do not turn the lens toward the sun. Strong light entering the lens when it is close to the Telephoto end may cause damage to the lens and the camera.

## **Control connectors**



1 LED power indicator

This indicator illuminates when the power is on, and goes out when the power is turned off.

2 Power switch

This is the switch for turning on/off the power.

③ AUX terminal

This terminal (HR10A-10R-10S (71) / HIROSE connector) is used to control optional functions. This can be used as a universal contact circuit.

AUX terminal's	pin	assignment
----------------	-----	------------

#### (4) SDI terminal

This is an output terminal (BNC connector) for uncompressed digital video and digital audio signals.

#### (5) SYNC terminal

This is an input terminal (BNC connector) for external sync signals.

6 DC-IN terminal


This is an input terminal for DC power supply. Make sure to use a power cable that is suitable for the installation conditions (authorized products, environmental regulations) and conforms to the product's power specifications. Power of two or three times the rating 90 W may be consumed during power-on, so select a power supply with specifications that prevent a power failure.

#### ⑦ CONT. terminal

This is an input terminal (EPRC05-R12M / TAJIMI connector) for the pan-tilt head, lens and camera control signals.

CONT. terminars pin assignment		
Pin No.	Input/output	Signal name
А	Input	RX+
В	Output	TX+
D	Input	RX-
Е	Output	TX-
J		GND

CONT terminal's nin assignment



- ⑧ Waterproof terminal for WASHER This is the control terminal for the washer (optional).
- (9) Waterproof terminal for MIC This is the control terminal for the microphone (optional).

# Pan-tilt head, housing, lens, and camera operation

Pan-tilt head and built-in lenses and camera are controlled from the operation unit.

The functions and operating procedures vary depending on the operation unit that is used. For further information, please refer to the instruction manual of your operation unit.

## 

• It may take about 20 seconds to output steady video signals after the camera is turned on.

#### **Genlock Synchronization**

- When a suitable Genlock signal is input, the Genlock synchronization stabilizes after approximately 10 seconds.
- After the Genlock signal is input, do not perform other operations until the video output signal stabilizes or during the adjustment of the phases.

## (i) NOTES

- If you operate the zoom after focusing, the focus on the subject may be lost.
- If you focus manually and then leave the camcorder with the power turned on, the focus on the subject may be lost after a while. This possible slight shift in focus is a result of the internal temperature rising in the camcorder and lens. Check the focus before resuming shooting.

# Custom picture settings

Using custom picture settings, you can change many settings that control various aspects of the image produced.

Available settings in Custom	picture settings
------------------------------	------------------

Classification by settings	Function	Menu settings	
	Gamma	[Gamma]	15
	Black gamma	[Black Gamma]	16
Cattings related to gradation	Master pedestal	[Black] - [Master Pedestal]	16
Settings related to gradation	Master black	[Black] - [Master Black]	16
	Knee	[Knee]	16
	Over 100%	[Other Functions] - [Over 100%]	18
	Sharpness level	[Sharpness] - [Level]	17
	Sharpness frequency	[Sharpness] - [Detail Frequency]	17
	Sharpness HV balance	[Sharpness] - [HV Detail Bal.]	17
Settings related to peak and noise	Sharpness limit	[Sharpness] - [Limit]	17
noiou	Coring level	[Sharpness] - [Coring Level]	17
	Noise reduction	[Noise Reduction]	17
	Skin detail	[Skin Detail]	17
	Color space	[Color Space]	15
	Color matrix	[Color Matrix]	15
	HLG Color	[HLG Color]	15
	Low key saturation	[Low Key Satur.]	16
Settings related to color	Knee saturation	[Knee] - [Saturation]	16
directivity, intense and conversion	Color gain	[Color Matrix Tuning] - [Gain]	17
	Color phase	[Color Matrix Tuning] - [Phase]	17
	Color tuning	[Color Matrix Tuning] - [R-G], [R-B], [G-R], [G-B], [B-R], [B-G]	17
	White balance	[White Balance]	17
	Color correction	[Color Correction]	17

## 

• If this product or the camera is turned off, adjusted values will be reset to default values.

## Selecting custom picture settings

You can select custom picture settings while checking the [Custom Picture] menu displayed on external monitors using operation unit.

## 

• While the CP menu is displayed, do not perform other operations except adjusting custom picture settings.

#### Selecting the gamma curve, color space and color matrix

CP	×
1	Custom Picture
Preset	Normal1:BT.709
	Normal1 : BT.2020
	Wide DR : BT.709
	Wide DR : BT.2020
	PQ : BT.2020
	HLG : BT.2020
	Canon Log 3 : BT.2020
	Canon Log 3 : BT.709
CP	×
1	Custom Picture
	Normal 1 (Standard)
Gamma	Normal 2 (x4.0)
	Normal 3 (BT.709)
	Normal 4 (x5.0)
	Wide DR
	Wide DR

#### 1 Select [C Custom Picture] ➤ [Preset].

- 2 Select the desired setting > press  $\leftarrow$  .
  - When not using the preset settings, select [Off] and continue the procedure with step 3.
  - To use one of the preset settings as is, the rest of the procedure is not necessary.
- 3 Select [ Custom Picture] ➤ [Gamma].
- 4 Select the desired setting > press  $\leftarrow$  .
- 5 Select [C Custom Picture] ➤ [Color Space], [ColorMatrix]. Repeat step 5, selecting [Color Space] to select the color space, and/or [Color Matrix] to select the color matrix in the same way.

#### Adjusting the image quality

To change the setting of [Master Pedestal]:

1 Select [C Custom Picture] > [Other Settings] > [Black] > [Master Pedestal].

2 Change the setting to the desired level > press  $\leftarrow$  .

### Available Custom Picture Settings

# [CP 1 Custom Picture] Menu

Menu items	Setting options and additional information
[Preset]	[Normal1 : BT.709], [Normal1 : BT.2020], [Wide DR : BT.709], [Wide DR : BT.2020], [PQ : BT.2020], [HLG : BT.2020], [Canon Log 3 : BT.709], [Off]
	The camera offers a number of preset color settings (combinations of color space, gamma curve and color matrix). [Off]: Select this setting when you want to set a different combination of custom picture settings with the individual custom picture settings described below.
[Gamma] Normal 2/3/4 Normal 1 Normal 4	[Normal 1 (Standard)], [Normal 2 (x4.0)], [Normal 3 (BT.709)], [Normal 4 (x5.0)], [Wide DR], [PQ], [HLG], [Canon Log 3]
Input	<ul> <li>Changes the overall look of the image.</li> <li>[Normal 1 (Standard)]: Standard picture for playback on TV monitors.</li> <li>[Normal 2 (x4.0)]: Setting suitable for playback on TV monitors. Produces brighter highlights (bright areas of the image) than with the [Normal 1 (Standard)] setting.</li> <li>[Normal 3 (BT.709)]: Setting suitable for playback on TV monitors. Produces a more faithful black gradation in the shadows (dark areas of the image) than with the [Normal 2 (x4.0)] setting.</li> <li>[Normal 4 (x5.0)]: Setting suitable for playback on TV monitors. Produces even better black gradation in the shadows (dark areas of the image) than with the [Normal 3 (BT.709)] setting.</li> <li>[Normal 4 (x5.0)]: Setting suitable for playback on TV monitors. Produces even better black gradation in the shadows (dark areas of the image) than with the [Normal 3 (BT.709)] setting.</li> <li>[Wide DR]: Gamma curve with a very wide dynamic range. Optimized for playback on TV monitors.</li> <li>[PQ]: HDR (high dynamic range) gamma curve compliant with the PQ standard defined by ITU-R BT.2100.</li> <li>[HLG]: HDR (high dynamic range) gamma curve compliant with the HLG standard defined by ITU-R BT.2100.</li> </ul>
HLG PQ Wide DR Normal1 Input	[Canon Log 3]: Logarithmic gamma curve that requires image processing in post-production.
[Color Space]	[BT.2020 Gamut], <b>[BT.709 Gamut]</b>
	Determines the color space of the image. [BT.2020 Gamut]: Color space that meets ITU-R BT.2020 standards, which defines parameters for ultra-high-definition television (4K/8K). [BT.709 Gamut]: Standard color space that is compatible with sRGB specifications.
[Color Matrix]	[Video], [Neutral]
	The color matrix affects the overall color tonality of the image. [Video]: Reproduces the colors of an EOS C300/EOS C500 camera with no custom picture settings applied. [Neutral]: Reproduces neutral colors.
[HLG Color]	[BT.2100], <b>[Vivid]</b>
	Changes the quality of color reproduction when using the hybrid log gamma (HLG). This setting is only available when [Gamma] is set to [HLG]. [BT.2100]: Color reproduction according to ITU-R BT.2100 specifications. [Vivid]: More saturated color reproduction according to the 'Traditional Colour' approach in ITU-R BT.2390.
[Activate Other Settings]	[ <b>On</b> ], [Off]

Setting options and additional information
–50 to 50 <b>(±0)</b>
Increases or decreases the black level. Higher settings will make dark areas brighter but decrease contrast. When [Gamma] is set to [Canon Log 3], this setting is not available.
–50 to 50 <b>(±0)</b>
These settings correct the color cast in blacks. When [Gamma] is set to [Canon Log 3], these settings are not available.
–50 to 50 <b>(±0)</b>
–20 to 50 <b>(±0)</b>
These settings control the lower part of the gamma curve (dark areas of the image). When [Gamma] is set to [Wide DR], [PQ], [HLG] or [Canon Log 3], these settings are not available. [Level]: Raises or lowers the lower part of the gamma curve. [Range]: Selects the adjustment range from the selected [Point]. [Point]: Determines the shape of the lower part of the gamma curve.
[On], <b>[Off]</b>
Set this setting to [On] to enable the adjustment of color saturation in dark areas with the [Level] setting.
–50 to 50 <b>(±0)</b>
Specifies how saturated colors are in dark areas.
<b>[On],</b> [Off]
Set this setting to [On] to enable the adjustment of the knee point with the following settings. When [Gamma] is set to [Wide DR],
[PQ], [HLG] or [Canon Log 3], the [Knee] settings are not available.
<b>[0n]</b> , [0ff]
Set this setting to [On] to enable the automatic adjustment of the [Knee] settings.
–35 to 50 <b>(±0)</b>
50 to 109 <b>(95)</b>
–10 to 10 <b>(±0)</b>
These settings control the upper part of the gamma curve (highlights of the image). By compressing the highlights, you can prevent parts of the image from being overexposed. [Slope]: Determines the slope of the gamma curve above the knee point. [Point]: Sets the knee point of the gamma curve. [Saturation]: Adjusts the color saturation in the highlights.

### 

Menu items	Setting options and additional information
[Sharpness]	
[Level]	–10 to 50 <b>(±0)</b>
	Sets the sharpness level of the video output signal and the recorded signal.
[Detail Frequency]	–8 to 8 <b>(±0)</b>
	Sets the center frequency of horizontal sharpness. Setting higher values increases the frequency, which, in turn, increases the sharpness.
[Coring Level]	–30 to 50 <b>(±0)</b>
	Sets the level of correction of artifacts caused by high sharpness levels (coring). Higher values prevent sharpness from being applied to minute details, resulting in less noise.
[HV Detail Bal.]	–8 to 8 <b>(±0)</b>
	Adjusts the ratio between horizontal and vertical detail. Higher values emphasize vertical detail while lower values emphasize horizontal detail.
[Limit]	–50 to 50 <b>(±0)</b>
	Restricts how much sharpness is applied.
[Noise Reduction]	
[Level]	[Automatic],1 (lowest level) to 12 (highest level), [Off]
	Reduces the amount of noise that appears in the image.
[Skin Detail]	
[Effect Level]	[High], [Middle], [Low], <b>[Off]</b>
[Hue]	-16 to 16 <b>(±0)</b>
[Chroma], [Area], [Y Level]	0 to 31 (16)
	The camera applies a softening filter to areas in the picture with skin tones to give a more pleasant appearance. By changing these settings, you can determine what areas will be detected as skin tones. A zebra pattern will appear on the screen over areas of the image that are detected as having skin tones. [Effect Level]: Adjusts the level of the filter. [Hue]: Adjusts the hue for detection of skin tones. [Chroma]: Adjusts the color saturation for detection of skin tones. [Area]: Adjusts the color range for detection of skin tones. [Y Level]: Adjusts the brightness for detection of skin tones.
[White Balance]	
[R Gain], [B Gain]	–50 to 50 <b>(±0)</b>
	These settings adjust the amount of white balance throughout the whole image by changing the intensity of red tones ([R gain]) and blue tones ([B Gain]).
[Color Matrix Tuning]	
[Gain]	–50 to 50 <b>(±0)</b>
[Phase]	–18 to 18 <b>(±0)</b>
	These settings adjust the color intensity ([Gain]) and color phase ([Phase]) of the color matrix, affecting the color tones of the whole image.
[R-G], [R-B], [G-R], [G-B],	-50 to 50 <b>(±0)</b>
[B-R], [B-G]	Each matrix changes the tint of the picture along the color gradations detailed below, affecting the color tones of the whole
	image. ID CL was (seen and rad/magenta: ID DL was/blue and rad/vallaur.
	[R-G]: cyan/green and red/magenta; [R-B]: cyan/blue and red/yellow; [G-R]: magenta/red and green/cyan; [G-B]: magenta/blue and green/yellow;
	[B-R]: yellow/red and blue/cyan; [B-G]: yellow/green and blue/magenta.
[Color Correction]	
[Select Area]	[Area A&B], [Area B], [Area A], <b>[Off]</b>
	The camera detects areas with certain color characteristics (color phase, chroma, area and Y level) and corrects them when recording. You can set the color correction for up to two different areas (A and B) and apply the color correction to either one ([Area A] or [Area B]) or both of them ([Area A&B]). While color correction is activated, a zebra pattern will appear on the screen over areas of the image detected as having the characteristics specified for area A or area B.
[Area A Setting Phase],	0 to 31 <b>(0)</b>
[Area B Setting Phase]	These settings determine the color phase of the area to be corrected (A or B, respectively).
[Area A Setting Chroma],	0 to 31 (16)
[Area A Setting Area], [Area A Setting Y Level], [Area B Setting Chroma], [Area B Setting Area], [Area B Setting Y Level]	These settings determine the following color characteristics of the area to be corrected (A or B, respectively). [Area A Setting Chroma], [Area B Setting Chroma]: Color saturation. [Area A Setting Area], [Area B Setting Area]: Color range. [Area A Setting Y Level], [Area B Setting Y Level]: Brightness.

Menu items	Setting options and additional information	
[Area A Revision Level],	–50 to 50 <b>(±0)</b>	
[Area B Revision Level]	These settings adjust the amount of correction applied to the color saturation in the corrected area (A or B, respectively).	
[Area A Revision Phase],	-18 to 18 (±0)	
[Area B Revision Phase]	These settings adjust the amount of correction applied to the color phase in the corrected area (A or B, respectively).	
[Other Functions]		
[Over 100%]	[Through], [Press], [Clip]	
	Determines how the camera handles video signals exceeding 100%. When [Gamma] is set to [PQ], [HLG] or [Canon Log 3], this setting is not available. [Through]: Leave the signal unchanged. [Clip]: Clip the signal at 100%. [Press]: Compress a signal of up to 108% down to 100% levels.	
[File]	This function is not available for this product. Do not operate it.	

# Additional information

# Troubleshooting

Symptom	Site where check is required	Check and confirm
Communication is not possible with the operation unit.	Installation site	Check that each cable is connected correctly.
Camera control does not work.	Installation site	<ul> <li>Check the power to the pan-tilt head.</li> <li>Check that the control cable for pan-tilt head and the cable for camera are connected correctly.</li> <li>Conduct a continuity check for broken cable wires, etc.</li> </ul>
No video is displayed although the pan- tilt head can be operated.	Installation site	• Conduct a continuity check for broken cable wires, etc. (Disconnect the BNC and check the video from the pan-tilt head.)
The pan-tilt head does not move.	Installation site	• This may be due to an outside factor such as strong wind or some obstacle. Check and remove any obstructing factors, and perform the operation again.
The custom picture settings cannot be selected using the operation unit.	Installation site	• [Activate Other Settings] in the custom picture settings was set to [Off]. Turn the camera off and then on again.

# Specifications

## Camera unit

Available menu items may vary depending on the operation unit used.


Imaging sensor	Type 1.0 (1.0 in.) sing	le-plate CMOS sensor,	effective pixels: approxi	mate 8,290,000 pixels									
Mounted camera	8.3 to 124.5 mm F2.	8 to 4.5, approximate 6	5.4 to 96 mm (Type 2/3 e	equivalent)									
	15x optical zoom, 30	x advanced zoom (only	when the resolution is <sup>-</sup>	1920x1080)									
Video Output Configuration	Model	Resolution*	Frame rate*	Video Output Configuration									
	CR-X500 1A	CR-X5001A 3840x2160 59.94P											
			29.97P	3840x2160 29.97P									
			23.98P	3840x2160 23.98P									
		1920x108059.94P1920x1080 59.59.94i1920x1080 59											
		29.97P1920x1080 29.923.98P1920x1080 23.9											
	CR-X5002A	CR-X5002A         3840x2160         50.00P         3840x2160 50           25.00P         3840x2160 25         3840x2160 25         3840x2160 25											
		1920x1080	50.00P	1920x1080 50.00P									
			50.00i	1920x1080 50.00i									
			25.00P	1920x1080 25.00P									
Default Video Dutput Configuration	CR-X5001A         1920x108           CR-X5002A         1920x108												
Focusing system	AUTO, MANUAL												
RIS	AUTO, MANUAL												
mage stabilizer	Optical shift type												
Shutter speed	AUTO												
	MANUAL												
	CR-X500 1A 59.94	P / 59.94i / 29.97P: 1/4	to 1/2000										
	23.98	P: 1/3 to 1/2000											
	CR-X5002A 1/3 to	1/2000											
Gain	AUTO												
	MANUAL												
	-6, -3, 0, 3, 6, 9,	12, 15, 18, 21, 24, 27,	30, 33 dB										
ND filter	OFF, 1/4, 1/16, 1/64												
Vhite balance	AUTO, Set A, Set B,	Daylight, Tungsten, Kel	vin										
Available Custom	White balance (R /B	gain), Master pedestal,	Master black (R / B),										
Picture Settings	Preset custom picture	e settings (Gamma, Co	lor Space, Color Matrix),	, Black Gamma, Knee,									
	Champions Nation Do	duction, Skin Detail, Co	lau Matuix										

\* For more information about video output configuration, please contact your Canon dealer or your Canon sales representative.

# Head unit (Pan-tilt section)

Ambient operating conditions	Temperature: -15 to +40°C, Humidit	y: 90%RH or less (non-condensing)	
Wind speed resistance	0 to 25 m/s: Operate normally, 25 to	35 m/s: Operable, 35 to 60 m/s: No	t destroyed
Power supply	10.5 to 15 V DC, 90 W Power of two or three times the ra with specifications that prevent a p	ting 90 W may be consumed during power failure.	power-on, so select a power supply
Wiper	Provided		
MIC input	Provided (Pedestal section)		
Washer	Control terminal provided (Pedestal s	section)	
Pan-tilt head operations		Operation angle	Operation speed
	Panning	-170° to +170°±5°	0.5°/s to 25°/s
	Tilting	-50° to +30°±5°	0.3°/s to 20°/s
Shot operations	Pan/tilt/zoom/focus		
Stopping accuracy	For both pan and tilt operations less forces are applied	than 7' when no external forces are a	applied, less than 6' when external
Dustproof and waterproof performance	IP55		
Acoustic noise	NC55 or less*		
	* NC55 or less when operating spee	d is 10°/s or less	
Control cable	RS-422 cable		
	Depending on the system configurat	ion, other unit or cable may be requir	ed.
Receptacle	DC, control (RS-422), SDI output, SN	YNC input, AUX	
Video output	BNC1 system, 12G-SDI, 6G-SDI, 30	G-SDI, HD-SDI output, embedded au	dio
GENLOCK input	BNC1 system (tri-value/BB)		
Pan-tilt head securing	Mounted with four M8 bolts		
Scouring			
Dimensions	Refer to the external view ( 22).		

# **External View**



# Index

## A

AUX terminal	11

C
Camera housing
Camera unit
Components
Connections9
CONT. terminal
Control connectors11
Custom picture
D

DC-IN terminal	11
----------------	----

## Е

External View
F
Ferrite core9
н
Handling
1
image settings
Installation7
L

## М

Microphone
O Operation unit6
Р
Panning
pan-tilt head6
Power switch11
R

## R

Range
Receptacle

## S

Safety wire
SDI terminal11
Specifications
SYNC terminal11
System connections

## Т

Tilt																1(	С
Troubleshooting																1	9

## W

Washer
Waterproof terminal for MIC12
Waterproof terminal for WASHER12
Waterproof tube
Waterproofing

# 各販売地域のお問い合わせ先 / Inquiries (by Sales Region) / 各销售地区的咨询方式

AMERICAS

Brazil	Canon do Brasil Industria e Comercio Ltda. http://www.canon.com.br/suporte Tel: +55 (11) 4950-5465
Canada	Canon Canada, Inc. http://canon.ca/en/Contact-Support/Pro-Photo-Video Tel: +1 905 863 8321
Mexico	Canon Mexicana, S. de R.L. de C.V. http://www.canon.com.mx/servicio/contactanos Tel:+52 55 5249 4900
USA	Canon U.S.A., Inc. http://usa.canon.com/support Tel(BCTV) : 800-423-5367(USA Only) Tel(Cinema Lens) : 855-246-3367(USA Only)
ASIA	
CHINA	佳能(中国)有限公司 http://www.canon.com.cn/supports/service.html 电话:+86(0)10-8513-9999
JAPAN	キヤノンマーケティングジャパン株式会社 http://canon.jp Tel: (03) 3740-3305
Korea	캐논코리아컨슈머이미징㈜ http://www.canon-ci.co.kr
South & Southeast Asia	Canon Singapore Pte. Ltd. http://www.canon-asia.com/bctv
TAIWAN	Canon Marketing (Taiwan) Co., Ltd. http://www.canon.com.tw/index.aspx
EUROPE, MIDDLE EAST, AFRICA	
OCEANIA	Canon Europe Ltd. http://www.canon-europe.com Tel:+44(0)20-8588-8000
	Canon Australia Pty. Ltd.
	http://www.canon.com.au



Canon Inc. 30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan Canon Europa N.V. Bovenkerkerweg 59, 1185 XB Amstelveen, The Netherlands http://www.canon-europe.com

The information in this document is verified as of June 2021. Subject to change without notice. Visit your local Canon website to download the latest version.