

Menu Route Map

Direct Connection	
Network Settings	
Select Wired/Wireless LAN	
Wired LAN, Wireless LAN	
Wireless LAN Settings	
WPS Push Button Mode	
WPS PIN Code Mode	
SSID Settings	
Select Access Point	
Enter Manually	
Security Settings	
None	
WEP	
Open System, Shared Key	
WPA/WPA2-PSK	
Auto, AES-CCMP	
Power Save Mode	
Off, On	
Connection Information	
MAC Address	
Wireless LAN Status	
Latest Error Information	
Channel	
SSID Settings	
Security Settings	
Power Save Mode	
Enable Direct Connection	
Off, On	
TCP/IP Settings	
IPv4 Settings	
IP Address Settings	
Auto Acquire	
Select Protocol	
Off, DHCP	
Auto IP	
Off, On	
Manually Acquire	
IP Address: 0.0.0.0	
Subnet Mask: 0.0.0.0	
Gateway Address: 0.0.0.0	
Check Settings	
Auto Acquire	
IP Address	
Subnet Mask	
Gateway Address	
PING Command	
DNS Settings	
DNS Server Settings	
Primary DNS Server: 0.0.0.0	
Secondary DNS Server: 0.0.0.0	
DNS Host Name/Domain Name Settings	
Host Name	
Domain Name	
DNS Dynamic Update Settings	
Off, On	
0 to 24 to 48 (hr.)	
mDNS Settings	
Off, On(mDNS Name)	
DHCP Option Settings	
Acquire Host Name	
Off, On	
DNS Dynamic Update	
Off, On	
Acquire DNS Server Address	
Off, On	
Acquire Domain Name	
Off, On	
Acquire WINS Server Address	
Off, On	
IPv6 Settings	
Use IPv6	
Off, On, Check Settings	
Link-Local Address	
Prefix Length	
Stateless Address Settings	
Off, On, Check Settings	
Stateless Address	
Prefix Length	
Use DHCPv6	
Off, On, Check Settings	
Stateful Address	
Prefix Length	
DNS Settings	
DNS Host Name/Domain Name Settings (Use IPv4 Host/Domain)	
Off, On	
Host Name	
Domain Name	
DNS Dynamic Update Settings	
Off, On	
Register Manual Address	
Off, On	
Register Stateful Address	
Off, On	
Register Stateless Address	
Off, On	
DNS Dynamic Update Interval	
0 to 24 to 48 (hr.)	
mDNS Settings	
Off, On(Use Same mDNS Name as IPv4)	
Off(mDNS Name), On	
DHCP Option Settings	
Acquire DNS Server Address	
Off, On	
Acquire Domain Name	
Off, On	
WINS Settings	
WINS Resolution	
Off, On(WINS Server Address: 0.0.0.0)	
LPD Settings	
LPD Print Settings	
Off, On	
RX Timeout	
1 to 5 to 60 (min.)	
RAW Settings	
RAW Print Settings	
Off, On	
RX Timeout	
1 to 5 to 60 (min.)	
WSD Settings	
WSD Print Settings	
Use WSD Print	
Off, On	
Use WSD Browsing	
Off, On	
Use Multicast Discovery	
Off, On	
Use HTTP	
Off, On	
IPP Print Settings	
Use IPP Printing	
Off, On	
Use TLS	
Off, On	

Port Number Settings	
LPD	
1 to 515 to 65535	
RAW	
1 to 9100 to 65535	
WSD Multicast Discovery	
1 to 3702 to 65535	
HTTP	
1 to 80 to 65535	
Multicast Discovery	
1 to 427 to 65535	
SNMP	
1 to 161 to 65535	
MTU Size	
1300, 1400, 1500	
SNMP Settings	
SNMPv1 Settings	
Off, On	
SNMPv3 Settings	
Off, On	
Acquire Printer Management Information from Host	
Off, On	
Dedicated Port Settings	
Off, On	
Waiting Time for Connection at Startup	
0 to 300 (sec.)	
Ethernet Driver Settings	
MAC Address	
Auto Detect	
Off, On	
Communication Mode	
Half Duplex, Full Duplex	
Ethernet Type	
10BASE-T, 100BASE-TX, 1000BASE-T	
IEEE 802.1X Settings	
Off, On	
Device Settings Management On/Off	
Off, On	
Monitoring Service	
Off, On	
Initialize Network Settings	

Output Reports	
Print List	
Consumables Status Report	
User Data List	
System Manager Data List	
Department ID Management Report	
IPSec Policy List	
PCL Font List	
Cartridge Log Report	

Preferences	
Volume Settings	
Entry Tone	
Off, On	
Invalid Entry Tone	
Off, On	
Restock Supplies Tone	
Off, On	
Job Done Tone	
Off, On	
Energy Saver Alert	
Off, On	
Display Settings	
Brightness	
Five Levels	
Contrast	
Seven Levels	
Invert Screen Colors	
Off, On	
Millimeter/Inch Entry Switch	
Millimeter, Inch	
Gram/Pound Switch	
Gram, Pound	
Message Display Time	
1 to 2 to 5 (sec.)	
Scrolling Speed	
Slow, Standard, Fast	
Cursor Movement Type	
Auto, Manual	
Language	
English, Japanese, French, Spanish, German, Italian, Portuguese, Chinese (Simplified), Chinese (Traditional), Korean	
Remote UI Language	
English, Japanese, French, Spanish, German, Italian, Portuguese, Chinese (Simplified), Chinese (Traditional), Korean	

Timer Settings	
Date/Time Settings	
Date Format	
YYYY MM/DD, MM/DD/YYYY, DD/MM YYYY	
Time Format	
12 Hour (AM/PM), 24 Hour	
Current Date/Time Settings	
Time Zone	
(UTC-12:00) International Date Line West to (UTC-05:00) Eastern Time (US & Canada) to (UTC+14:00) Christmas Island	
Daylight Saving Time Settings	
Off, On	
Start: Month, Week, Day	
End: Month, Week, Day	
Auto Reset Time	
0=Off (Auto Reset is disabled.), 1 to 2 to 9 (min.)	
Auto Sleep Time	
3 to 240 (min.)	

Common Settings	
Switch Paper Feed Method	
Multi-Purpose Tray	
Speed Priority, Print Side Priority	
Drawer 1	
Speed Priority, Print Side Priority	
Drawer 2	
Speed Priority, Print Side Priority	

Settings marked with an asterisk (*) are only available when the optional paper feeder (drawer 2) is attached.

Printer Settings	
Action When Free Paper Size Mismatch	
Multi-Purpose Tray	
Force Output, Display Error	
Drawer 1	
Force Output, Display Error	
Drawer 2	
Force Output, Display Error	
Copies	
1 to 99	
2-Sided Printing	
Off, On	
Default Paper	
Paper Size Override	
Off, On	
Print Quality	
Density	
17 Levels	
Fine Adjust	
High(17 Levels)	
Medium(17 Levels)	
Low(17 Levels)	
Toner Save	
Off, On	
Resolution	
1200 dpi, 600 dpi	
Barcode Adjustment Mode	
Off, On	
Mode 1, Mode 2, Mode 3	
Layout	
Binding Location	
Long Edge, Short Edge	
Gutter	
-1.90 to 0.00 to +1.90 (inches) or -50.0 to 0.00 to +50.0 (mm)	
Offset Short Edge/Offset Long Edge	
-2.00 to 0.00 to +2.00 (inches) or -50.0 to 0.00 to +50.0 (mm)	
Auto Error Skip	
Off, On	
Timeout	
5 to 15 to 300 (sec.)	
Prioritize Multi-Purpose Tray	
Off, On	
UFR II	
Halftones	
Text	
Resolution, Color Tone, Gradation, High Resolution	
Graphics	
Resolution, Color Tone, Gradation, High Resolution	
Image	
Resolution, Color Tone, Gradation, High Resolution	
PCL	
Paper Save	
Off, On	
Orientation	
Portrait, Landscape	
Font Number	
0 to 54	
Point Size	
4.00 to 12.00 to 999.75 (point)	
Pitch	
0.44 to 10.00 to 99.99 (cpi)	
Form Lines	
5 to 60 to 128 (lines)	
Character Code	
DESKTOP, ISO4, ISO6, ISO11, ISO15, ISO17, ISO21, ISO60, ISO69, ISO11, ISO12, ISO15, ISO16, LEGAL, MATH8, MCTEXT, MSPUBL, PC775, PC8, PC850, PC852, PC8DN, PC8TK, PC1004, PIFONT, PSMATH, PSTEXT, ROMANS, VNINTL, VNMMATH, VNUS, WIN30, WINBALT, WINL1, WINL2, WINL5	
Custom Paper	
Off, On	
Unit of Measure	
Millimeters, Inches	
X dimension	
3 to 8 1/2 (inches) or 77 to 216 (mm)	
Y dimension	
5 to 14 (inches) or 127 to 356 (mm)	
Append CR to LF	
Yes, No	
Enlarge A4 Print Width	
Off, On	
Halftones	
Text	
Resolution, Color Tone, Gradation, High Resolution	
Graphics	
Resolution, Color Tone, Gradation, High Resolution	
Image	
Resolution, Color Tone, Gradation, High Resolution	

Settings marked with an asterisk (*) are only available when the optional paper feeder (drawer 2) is attached.

Adjustment/ Maintenance	
Display Timing for Cartridge Preparation Notification	
Auto	
Custom	
1 to 20 to 99 (%)	
Printer Density	
Nine Levels	
Toner Save	
Off, On	
Adjust Print Position	
Multi-Purpose Tray	
Adjust Vertically (Front Side)	
-0.20 to 0.00 to +0.20 (*) or -5.0 to 0.0 to +5.0 (mm)	
Adjust Horizontally (Front Side)	
-0.12 to 0.00 to +0.12 (*) or -3.0 to 0.0 to +3.0 (mm)	
Adjust Vertically (Back Side)	
-0.20 to 0.00 to +0.20 (*) or -5.0 to 0.0 to +5.0 (mm)	
Adjust Horizontally (Back Side)	
-0.12 to 0.00 to +0.12 (*) or -3.0 to 0.0 to +3.0 (mm)	
Drawer 1	
Adjust Vertically (Front Side)	
-0.20 to 0.00 to +0.20 (*) or -5.0 to 0.0 to +5.0 (mm)	
Adjust Horizontally (Front Side)	
-0.12 to 0.00 to +0.12 (*) or -3.0 to 0.0 to +3.0 (mm)	
Adjust Vertically (Back Side)	
-0.20 to 0.00 to +0.20 (*) or -5.0 to 0.0 to +5.0 (mm)	
Adjust Horizontally (Back Side)	
-0.12 to 0.00 to +0.12 (*) or -3.0 to 0.0 to +3.0 (mm)	

Drawer 2*	
Adjust Vertically (Front Side)	
-0.20 to 0.00 to +0.20 (*) or -5.0 to 0.0 to +5.0 (mm)	
Adjust Horizontally (Front Side)	
-0.12 to 0.00 to +0.12 (*) or -3.0 to 0.0 to +3.0 (mm)	
Adjust Vertically (Back Side)	
-0.20 to 0.00 to +0.20 (*) or -5.0 to 0.0 to +5.0 (mm)	
Adjust Horizontally (Back Side)	
-0.12 to 0.00 to +0.12 (*) or -3.0 to 0.0 to +3.0 (mm)	
Special Processing	
Special Printing Mode A	
Off, Mode 1, Mode 2, Mode 3, Mode 4	
Special Printing Mode U	
Off, On	
Special Printing Mode V	
Off, Mode 1, Mode 2	
Special Printing Mode B	
Off, Mode 1, Mode 2, Mode 3	
Special Printing Mode D	
Off, On	
Clean Fixing Assembly	

Settings marked with an asterisk (*) are only available when the optional paper feeder (drawer 2) is attached.

System Management Settings	
Network Settings	
->Network Settings	
System Manager Information Settings	
System Manager ID and PIN	
System Manager ID	
System Manager PIN	
System Manager Name	
Device Information Settings	
Device Name	
Location	
Department ID Management On/Off	
Off, On	
Security Settings	
Use TLS	
Off, On	
Use IPSec	
Off, On	
IPv4 Address Filter	
Outbound Filter	
Off, On	
Inbound Filter	
Off, On	
IPv6 Address Filter	
Outbound Filter	
Off, On	
Inbound Filter	
Off, On	
MAC Address Filter	
Outbound Filter	
Off, On	
Inbound Filter	
Off, On	
Select Country/Region	
United States (US), Canada (CA), Brazil (BR), Mexico (MX), Other	
Remote UI Settings	
Use Remote UI	
Off, On	
Remote UI Access Security Settings	
Off, On	
Remote UI Access PIN	
Display Job Log	
Off, On	
Use as USB Device	
Off, On	
Enable Product Extended Survey Program	
Off, On	
Display Consumables Information (RUI/Toner Status)	
Display Consumables Purchase Button (RUI)	
Off, On	
Toner Status Settings	
Off, On (Displ. Consumbls. Purchase Btn.)	
Off, On	
Google Cloud Print Settings	
Enable Google Cloud Print	
Off, On	
Google Cloud Print Registration Status	
Notify to Check Paper Settings	
Off, On	
Import/Export of Settings	
Import	
Export	
PDL Selection (Plug and Play)	
Network	
UFR II, UFR II (V4), PCL5, PCL6	
USB	
UFR II, UFR II (V4), PCL5, PCL6	
Update Firmware	
Via PC	
Via Internet	
Version Information	
Initialize Key and Certificate	
Initialize Menu	
Preferences	
Timer Settings	
Common Settings	
Printer Settings	
System Management Settings	
Network Settings	
System Manager Information Settings	
Device Information Settings	
Department ID Management On/Off	
Display Job Log	
Use as USB Device	
Enable Product Extended Survey Program	
Information for Purchasing Consumables	
Google Cloud Print Settings	
Notify to Check Paper Settings	
PDL Selection (Plug and Play)	
Initialize All	
Initialize All Data/Settings	